

# FLIP-OPEN OBJECTIVE LENS COVERS - BUTLER CREEK OBJECTIVE LENS COVER #15 1.558" (39.6MM)

[Optics & Mounting](#) > [Optic Accessories](#) > [Scope Lens Covers](#)

## Keeps Harmful Debris From Scratching Or Abusing Lenses

Weatherproof, dust-proof, moisture-proof scope covers protect your scope's lenses from being damaged during tactical and hunting situations. Cover flips open easily with finger pressure to spring up, and out of the way. Eye and Objective covers sold separately. To determine the correct scope cover, measure the diameter of your scope eyepiece or objective and use the chart.



## Attributes

- Name: [BUTLER CREEK OBJECTIVE LENS COVER #15 1.558" \(39.6MM\)](#)
- Manufacturer: [BUTLER CREEK](#)
- Product no.: 120000027
- Mfr. No.: 30150
- Colour: Black
- End Fit: Objective
- Model Number: 1.558" (39.6MM)
- Size: 1.558
- Delivery weight: 0.027kg
- Shipping height: 38mm
- Shipping width: 69mm
- Shipping length: 119mm
- UPC: 051525301509

# Table of Contents

- Startpage
- FLIOPEN OBJECTIVE LENS COVERS SAFETY INSTRUCTIONS
- About Us

# FLIPOOPEN OBJECTIVE LENS COVERS SAFETY INSTRUCTIONS

## Introduction

Thank you for choosing the FLIPOOPEN OBJECTIVE LENS COVERS by Butler Creek. These lens covers are designed to protect your scope's lenses from weather, dust, and moisture during tactical and hunting situations. Please read this safety instruction guide carefully to ensure safe usage and compliance with EU General Product Safety Regulations (GPSR).

## General Safety Guidelines

- Ensure safe use of the product by following all instructions.
- Regularly check for any signs of wear or damage to the lens covers.
- Keep lens covers out of reach of children to prevent accidental misuse.
- Report any unsafe product conditions or accidents to the relevant authorities.
- Check for recall updates on the EU's Safety Gate platform.

## Specific Safety Precautions for Use

- Always ensure that the lens covers are securely attached to your scope when not in use.
- Avoid using excessive force when flipping the cover open or closed.
- Do not attempt to modify or alter the lens covers in any way.
- Inspect the lens covers before each use for any signs of damage or wear.
- If the lens covers become damaged, discontinue use and replace them immediately.

## Instructions for Installation and Usage

### 1. Measuring Your Scope:

- Before purchasing, measure the diameter of your scope eyepiece or objective to ensure you select the correct size.
- Use the provided chart to determine the right lens cover size.

### 2. Installation:

- Align the lens cover with the scope's eyepiece or objective.
- Gently press the cover into place until it fits snugly.

### 3. Using the Lens Covers:

- To open the cover, apply light finger pressure to the designated area.
- The cover will spring open and remain out of the way for easy viewing.
- To close, simply press the cover back into place until it clicks securely.

### 4. Maintenance:

- Clean the lens covers regularly with a soft, dry cloth.
- Avoid using harsh chemicals or abrasive materials that may damage the covers.

## Disposal Instructions

- Dispose of the lens covers in accordance with local waste management regulations.

- Do not dispose of the product in household waste. Instead, recycle where possible to minimize environmental impact.

## **Contact Information for Further Support**

For any questions or concerns regarding the FLIOPEN OBJECTIVE LENS COVERS, please refer to the contact information provided with your product packaging or visit the manufacturer's website for further assistance.

By following these safety instructions, you can ensure the optimal performance and longevity of your FLIOPEN OBJECTIVE LENS COVERS. Thank you for your attention to safety and for choosing Butler Creek.

# About Us

## Brownells UK

### **Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories**

Unit 1, Laughing Dog Industrial Estate  
London Road  
Rugby  
Warwickshire  
CV23 9LP

[www.brownells.co.uk](http://www.brownells.co.uk)