

FLIP-OPEN OBJECTIVE LENS COVERS - BUTLER CREEK OBJECTIVE LENS COVER #33 2.043" (51.9MM)

[Optics & Mounting](#) > [Optic Accessories](#) > [Scope Lens Covers](#)

Keeps Harmful Debris From Scratching Or Abusing Lenses

Weatherproof, dust-proof, moisture-proof scope covers protect your scope's lenses from being damaged during tactical and hunting situations. Cover flips open easily with finger pressure to spring up, and out of the way. Eye and Objective covers sold separately. To determine the correct scope cover, measure the diameter of your scope eyepiece or objective and use the chart.



Attributes

- Name: [BUTLER CREEK OBJECTIVE LENS COVER #33 2.043" \(51.9MM\)](#)
- Manufacturer: [BUTLER CREEK](#)
- Product no.: 120000030
- Mfr. No.: 30330
- Colour: Black
- End Fit: Objective
- Model Number: 2.043" (51.9MM)
- Size: 2.043
- Delivery weight: 0.045kg
- Shipping height: 38mm
- Shipping width: 69mm
- Shipping length: 122mm
- UPC: 051525303305

Table of Contents

- Startpage
- FLIOPEN OBJECTIVE LENS COVERS SAFETY INSTRUCTIONS
- About Us

FLIPOOPEN OBJECTIVE LENS COVERS SAFETY INSTRUCTIONS

Introduction

Thank you for choosing the FLIPOOPEN OBJECTIVE LENS COVERS by Butler Creek. These lens covers are designed to protect your scope's lenses from dust, moisture, and damage during tactical and hunting situations. This safety instruction guide provides essential information to ensure safe and effective use of the product in compliance with the EU General Product Safety Regulation (GPSR).

General Safety Guidelines

- Ensure that the lens covers are compatible with your scope by measuring the diameter of your scope eyepiece or objective.
- Always inspect the lens covers for any damage before use. Do not use if damaged.
- Keep lens covers out of reach of children to prevent accidental use or ingestion.
- Do not expose the lens covers to extreme temperatures or harsh chemicals.
- Report any unsafe product experiences or accidents to the relevant authorities.

Specific Safety Precautions for Use

- Use the lens covers only for their intended purpose of protecting scope lenses.
- Avoid using excessive force when flipping the covers open or closed to prevent breakage.
- Ensure that the lens covers are securely attached before using your scope to avoid accidental detachment.
- Be cautious of sharp edges or components when handling the lens covers.
- If you notice any unusual operation or damage, discontinue use immediately and seek assistance.

Instructions for Installation and Usage

1. Measuring for Compatibility:

- Measure the diameter of your scope's eyepiece or objective using a caliper or ruler.
- Refer to the provided chart to select the correct size lens cover.

2. Installation:

- Align the lens cover with the eyepiece or objective of the scope.
- Gently press the cover into place until it is securely fitted.

3. Using the Lens Covers:

- To open the cover, apply gentle finger pressure to the designated area.
- The cover will spring open easily; ensure it is fully opened before using the scope.
- After use, close the cover by pushing it back down until it clicks into place.

4. Maintenance:

- Regularly clean the lens covers with a soft, dry cloth to remove dust or debris.
- Avoid using abrasive materials or solvents that may damage the lens covers.

Disposal Instructions

- Dispose of the lens covers in accordance with local regulations for plastic waste.
- Do not incinerate or expose the lens covers to open flames.
- If the product is no longer usable, consider recycling options available in your area.

Contact Information for Further Support

For any inquiries regarding the safety and use of the FLIOPEN OBJECTIVE LENS COVERS, please refer to the contact information provided on the packaging or visit the manufacturer's website.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk