

FLIP OPEN EYEPIECE LENS COVERS - BUTLER CREEK EYEPIECE LENS COVER #3 1.388" (35.3MM)

[Optics & Mounting](#) > [Optic Accessories](#) > [Scope Lens Covers](#)

Keeps Harmful Debris From Scratching Or Abusing Lenses

Weatherproof, dust-proof, moisture-proof scope covers protect your scope's lenses from being damaged during tactical and hunting situations. Cover flips open easily with finger pressure to spring up, and out of the way. Eye and Objective covers sold separately. To determine the correct scope cover, measure the diameter of your scope eyepiece or objective and use the chart.



Attributes

- Name: [BUTLER CREEK EYEPIECE LENS COVER #3 1.388" \(35.3MM\)](#)
- Manufacturer: [BUTLER CREEK](#)
- Product no.: 120000040
- Mfr. No.: MO20035
- Colour: Black
- End Fit: Ocular
- Model Number: 1.388" (35.3MM)
- Optic Model: -
- Size: 1.388
- Delivery weight: 0.027kg
- Shipping height: 38mm
- Shipping width: 69mm
- Shipping length: 122mm
- UPC: 051525200352

Table of Contents

- Startpage
- Safety Instruction Guide for Butler Creek Eyepiece Lens Cover #3
- About Us

Safety Instruction Guide for Butler Creek Eyepiece Lens Cover #3

Introduction

Thank you for choosing the Butler Creek Eyepiece Lens Cover #3. This product is designed to protect your scope's lenses from damage due to weather, dust, and moisture during tactical and hunting situations. To ensure your safety and the effective use of this product, please read and follow the guidelines outlined in this instruction manual.

General Safety Guidelines

- Ensure safe use of the product by following all instructions.
- Regularly inspect the lens cover for any signs of wear or damage.
- Keep the product out of reach of children to prevent accidents or misuse.
- Report any unsafe conditions or accidents involving the product to the appropriate authorities.
- Stay informed about product recalls by checking the EU's Safety Gate platform.

Specific Safety Precautions for Use

- Do not force the cover open; use gentle finger pressure to flip it open.
- Avoid using the lens cover in extreme conditions that exceed its intended use.
- Ensure the cover is securely attached to prevent it from detaching during use.
- Do not expose the lens cover to sharp objects that may cause punctures or tears.
- Store the lens cover in a cool, dry place when not in use to prolong its life.

Instructions for Installation and Usage

1. Measuring Your Scope:

- Measure the diameter of your scope eyepiece or objective to ensure you select the correct lens cover size.
- Use the provided chart to confirm that the Butler Creek Eyepiece Lens Cover #3 (1.388" or 35.3mm) is suitable for your scope.

2. Attaching the Lens Cover:

- Align the lens cover with the eyepiece of your scope.
- Press firmly until the lens cover fits snugly over the eyepiece.
- Ensure that the cover is securely attached and does not wobble.

3. Using the Lens Cover:

- To open the lens cover, apply gentle pressure with your finger on the designated area.
- The cover will spring up and out of the way, allowing you to use your scope without obstruction.
- When finished, gently close the lens cover to protect the lenses from dust and moisture.

Disposal Instructions

- Dispose of the lens cover in accordance with local regulations for plastic products.
- Do not incinerate or compost the lens cover.
- If the product is damaged beyond use, ensure it is disposed of safely to prevent environmental harm.

Contact Information for Further Support

For any inquiries regarding the safety or use of the Butler Creek Eyepiece Lens Cover #3, please refer to the relevant EUbased contact point for assistance.

Thank you for your attention to these safety instructions. Enjoy your experience with the Butler Creek Eyepiece Lens Cover #3 while ensuring your safety and that of others.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk