

FLIP-OPEN OBJECTIVE LENS COVERS - OBJECTIVE LENS COVER #39 2.220" (56.4MM)

[Optics & Mounting](#) > [Optic Accessories](#) > [Scope Lens Covers](#)

Keeps Harmful Debris From Scratching Or Abusing Lenses

Weatherproof, dust-proof, moisture-proof scope covers protect your scope's lenses from being damaged during tactical and hunting situations. Cover flips open easily with finger pressure to spring up, and out of the way. Eye and Objective covers sold separately. To determine the correct scope cover, measure the diameter of your scope eyepiece or objective and use the chart.



Attributes

- Name: [OBJECTIVE LENS COVER #39 2.220" \(56.4MM\)](#)
- Manufacturer: [BUTLER CREEK](#)
- Product no.: 120000044
- Mfr. No.: 30390
- Color: Black
- End Fit: Objective
- Model Number: 2.220" (56.4MM)
- Size: 2.22
- Delivery weight: 0.068kg
- Shipping height: 33mm
- Shipping width: 94mm
- Shipping length: 150mm
- UPC: 051525303909

Table of Contents

- Startpage
- FLIOPEN OBJECTIVE LENS COVERS SAFETY INSTRUCTIONS
- About Us

FLIPOOPEN OBJECTIVE LENS COVERS SAFETY INSTRUCTIONS

Introduction

Thank you for choosing the FLIPOOPEN OBJECTIVE LENS COVERS. These covers are designed to protect your scope's lenses from damage during tactical and hunting situations. This safety instruction guide will provide you with essential information to ensure safe and effective use of the product in compliance with the EU General Product Safety Regulation (GPSR).

General Safety Guidelines

- Always inspect the lens covers for any signs of damage before use. Do not use if damaged.
- Ensure the covers are properly secured to prevent accidental detachment during use.
- Keep lens covers out of reach of children to prevent potential choking hazards.
- Avoid using the covers in extreme weather conditions beyond their intended use.
- Report any unsafe products or accidents to the relevant authorities.

Specific Safety Precautions for Use

- Use only for the intended purpose of protecting scope lenses.
- Do not apply excessive force when flipping the cover open as it may cause damage.
- Ensure that your hands are clean and dry when handling the lens covers to avoid dirt or moisture contamination.
- Avoid exposing the lens covers to sharp objects that may puncture or tear the material.
- If you experience any difficulty in using the covers, stop use immediately and refer to the instructions.

Instructions for Installation and Usage

1. Measuring Your Scope:

- Measure the diameter of your scope eyepiece or objective using a ruler or caliper.
- Refer to the provided chart to select the correct lens cover size.

2. Installing the Lens Covers:

- Align the lens cover with the eyepiece or objective lens.
- Gently press the cover onto the lens until it fits securely.
- Ensure that the cover is flush against the lens to provide maximum protection.

3. Using the Lens Covers:

- To open the cover, apply gentle finger pressure to the designated area.
- The cover will spring open and out of the way, allowing clear visibility.
- When finished, close the cover by gently pushing it back into place.

4. Maintenance:

- Clean the lens covers regularly with a soft, dry cloth to remove dust and debris.
- Avoid using harsh chemicals or abrasive materials that may damage the cover.

Disposal Instructions

- Dispose of the lens covers according to local regulations.
- Do not dispose of the product in household waste; instead, use designated recycling facilities if available.
- Ensure that any discarded parts are kept out of reach of children.

Contact Information for Further Support

For any inquiries regarding safety or product issues, please reach out to the appropriate EUbased contact. Ensure you have the product details at hand for efficient assistance.

Thank you for your attention to these safety instructions. Enjoy the reliable protection of your FLIOPEN OBJECTIVE LENS COVERS!

About Us

Brownells Austria

Brownells - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

www.brownells.at