

FLIP-OPEN OBJECTIVE LENS COVERS - BUTLER CREEK OBJECTIVE LENS COVER #20 1.700" (43.2MM)

[Optics & Mounting](#) > [Optic Accessories](#) > [Scope Lens Covers](#)

Keeps Harmful Debris From Scratching Or Abusing Lenses

Weatherproof, dust-proof, moisture-proof scope covers protect your scope's lenses from being damaged during tactical and hunting situations. Cover flips open easily with finger pressure to spring up, and out of the way. Eye and Objective covers sold separately. To determine the correct scope cover, measure the diameter of your scope eyepiece or objective and use the chart.



Attributes

- Name: [BUTLER CREEK OBJECTIVE LENS COVER #20 1.700" \(43.2MM\)](#)
- Manufacturer: [BUTLER CREEK](#)
- Product no.: 120000055
- Mfr. No.: 30200
- Colour: Black
- End Fit: Objective
- Model Number: 1.700" (43.2MM)
- Size: 1.7
- Delivery weight: 0.025kg
- Shipping height: 41mm
- Shipping width: 69mm
- Shipping length: 122mm
- UPC: 051525302001

Table of Contents

- Startpage
- FLIOPEN OBJECTIVE LENS COVERS SAFETY INSTRUCTIONS
- About Us

FLIPOOPEN OBJECTIVE LENS COVERS SAFETY INSTRUCTIONS

Introduction

Thank you for choosing the Butler Creek Objective Lens Cover #20. This product is designed to protect your scope's lenses from dust, moisture, and other potential damages during tactical and hunting situations. Please read this safety instruction guide carefully to ensure the safe and effective use of your lens covers.

General Safety Guidelines

- Always inspect the lens covers before use to ensure they are in good condition.
- Keep lens covers out of reach of children to prevent accidental injury or misuse.
- Ensure that the lens covers are compatible with your scope by measuring the diameter of the eyepiece or objective.
- Follow all manufacturer guidelines and recommendations for use and maintenance.

Specific Safety Precautions for Use

- Do not use the lens covers if they show signs of damage, such as cracks or warping.
- Avoid exposing the lens covers to extreme temperatures or direct sunlight for extended periods.
- When opening the lens covers, do so gently to avoid sudden movements that could cause injury.
- If the lens covers become wet, allow them to dry completely before storing or using them again.

Instructions for Installation and Usage

1. Measuring Your Scope:

- Measure the diameter of your scope eyepiece or objective to ensure you have the correct size lens cover.
- Use the provided chart to confirm compatibility.

2. Installing the Lens Covers:

- Align the lens cover with the eyepiece or objective.
- Gently press the cover into place until it fits securely.

3. Using the Lens Covers:

- To open the lens cover, apply light finger pressure to the designated area.
- The cover will spring open easily and should remain out of the way during use.

4. Removing the Lens Covers:

- To remove, gently pull the cover away from the scope.
- Store the lens covers in a safe place when not in use.

Disposal Instructions

- Dispose of any damaged or unusable lens covers in accordance with local regulations.
- If applicable, recycle materials according to local recycling guidelines.

Contact Information for Further Support

For any inquiries regarding the safety or usage of the Butler Creek Objective Lens Covers, please reach out to your local distributor or retailer.

Conclusion

By following these safety instructions, you can ensure the proper use and longevity of your Butler Creek Objective Lens Covers. Enjoy your tactical and hunting experiences with peace of mind, knowing your equipment is well protected.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk