

BLIZZARD SCOPE LENS COVERS - BLIZZARD LENS COVER #5 1.6-1.69" (40.6-42.9MM)

[Optics & Mounting](#) > [Optic Accessories](#) > [Scope Lens Covers](#)

Clear, See-Thru Caps Flip Open With Just A Touch

Spring-loaded, flip-open scope covers allow fast, thru-the-scope sighting for quick, off-hand shots. Impact resistant, polymer lenses keep your scope lens dry and clear during inclement weather and ready for your next shot.



Attributes

- Name: [BLIZZARD LENS COVER #5 1.6-1.69" \(40.6-42.9MM\)](#)
- Manufacturer: [BUTLER CREEK](#)
- Product no.: 120250005
- Mfr. No.: 70205
- Color: Black
- Model Number: 1.6-1.69" (40.6-42.9MM)
- Size: 1.605,1.612,1.646,1.65,1.66,1.675
- Delivery weight: 0.027kg
- Shipping height: 38mm
- Shipping width: 69mm
- Shipping length: 119mm
- UPC: 051525702054

Table of Contents

- Startpage
- Safety Instruction Guide for BLIZZARD SCOPE LENS COVERS
- About Us

Safety Instruction Guide for BLIZZARD SCOPE LENS COVERS

Introduction

Thank you for choosing the BLIZZARD SCOPE LENS COVERS. These lens covers are designed to provide reliable protection for your scope lenses, ensuring clarity and safety during use. This guide contains important safety instructions and recommendations to help you use the product correctly and safely.

General Safety Guidelines

- Always inspect the lens covers before use to ensure they are free from damage.
- Keep the lens covers out of reach of children to prevent accidental injury or misuse.
- Use the lens covers only for their intended purpose, which is to protect scope lenses.
- Be aware of your surroundings when using the scope to avoid accidents.

Specific Safety Precautions for Use

- Ensure that the lens covers are securely attached to the scope before use.
- Do not force the covers open or closed; use the springloaded mechanism gently.
- Avoid exposure to extreme temperatures, as this may affect the performance of the polymer lenses.
- If the lens covers become damaged, discontinue use immediately and replace them.

Instructions for Installation and Usage

1. Installation:

- Select the appropriate size lens cover for your scope. The BLIZZARD LENS COVER #5 is suitable for lenses measuring 1.61.69 inches (40.642.9 mm).
- Align the lens cover with the scope lens and press firmly until it clicks into place.
- Repeat the process for the other lens cover if applicable.

2. Usage:

- To open the lens covers, gently press on the designated area to flip them open.
- Ensure the lens is clear of obstructions before taking a shot.
- After use, close the lens covers to protect against dust and moisture.

Disposal Instructions

- Dispose of the lens covers in accordance with local regulations for plastic waste.
- Do not incinerate the lens covers, as this may release harmful substances into the environment.
- If you are unsure of the disposal methods, consult your local waste management authority.

Contact Information for Further Support

For any inquiries regarding the safety and use of the BLIZZARD SCOPE LENS COVERS, please contact the manufacturer or your local retailer. They can provide you with the necessary support and information.

Conclusion

By following the guidelines outlined in this safety instruction guide, you can ensure the safe and effective use of

your BLIZZARD SCOPE LENS COVERS. Always prioritize safety and be proactive in reporting any unsafe conditions or products. Thank you for your attention to these important safety measures.

About Us

Brownells Austria

Brownells - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

www.brownells.at