

# BLIZZARD SCOPE LENS COVERS - BLIZZARD LENS COVER #6 1.7-1.79" (43.1-45.5MM)

[Optics & Mounting](#) > [Optic Accessories](#) > [Scope Lens Covers](#)

## Clear, See-Thru Caps Flip Open With Just A Touch

Spring-loaded, flip-open scope covers allow fast, thru-the-scope sighting for quick, off-hand shots. Impact resistant, polymer lenses keep your scope lens dry and clear during inclement weather and ready for your next shot.



## Attributes

- Name: [BLIZZARD LENS COVER #6 1.7-1.79" \(43.1-45.5MM\)](#)
- Manufacturer: [BUTLER CREEK](#)
- Product no.: 120250006
- Mfr. No.: 70206
- Color: Black
- Model Number: 1.7-1.79" (43.1-45.5MM)
- Size: 1.7,1.73,1.735,1.76,1.775,1.79
- Delivery weight: 0.023kg
- Shipping height: 38mm
- Shipping width: 69mm
- Shipping length: 122mm
- UPC: 051525702061

# Table of Contents

- Startpage
- Safety Instruction Guide for BLIZZARD SCOPE LENS COVERS
- About Us

# Safety Instruction Guide for BLIZZARD SCOPE LENS COVERS

## Introduction

Thank you for purchasing the BLIZZARD SCOPE LENS COVERS. This guide provides essential safety instructions and guidelines to ensure the safe and effective use of your product. Please read this document carefully to understand how to use, maintain, and dispose of the lens covers properly.

## General Safety Guidelines

- Always inspect the lens covers for any damage before use. Do not use if damaged.
- Ensure that the scope is securely mounted and that the lens covers are properly attached.
- Keep the lens covers away from children to prevent accidental injury.
- Use the lens covers only for their intended purpose as described in this guide.
- Be aware of your surroundings when using the scope to avoid accidents.

## Specific Safety Precautions for Use

- Impact Resistance:** The polymer lenses are impact resistant; however, avoid dropping or striking them against hard surfaces.
- Weather Conditions:** While the lens covers are designed to keep your scope dry, avoid exposing the scope to extreme weather conditions for prolonged periods.
- Cleaning:** Clean the lenses with a soft, lintfree cloth. Avoid using harsh chemicals or abrasive materials that could scratch the lens.
- Storage:** Store the lens covers in a cool, dry place when not in use to prevent damage.

## Instructions for Installation and Usage

### 1. Installation:

- Locate the appropriate size of the lens covers for your scope (1.71.79 inches).
- Align the lens covers with the scope's lens opening.
- Gently press the covers onto the lens until they are securely in place.

### 2. Usage:

- To open the lens covers, simply flip them open using the springloaded mechanism.
- Ensure that the covers are fully open before aiming through the scope.
- After use, close the lens covers to protect the lens from dust and moisture.

## Disposal Instructions

- Dispose of the lens covers in accordance with local waste disposal regulations.
- If the lens covers are no longer functional, consider recycling materials where possible.
- Do not dispose of in fire, as the polymer may release harmful substances when burned.

## Contact Information for Further Support

For any safety inquiries or support, please refer to the product packaging or visit the manufacturer's website.

## **Conclusion**

By following these safety guidelines and instructions, you can ensure the safe and effective use of your BLIZZARD SCOPE LENS COVERS. Always prioritize safety and be aware of your surroundings while using this product. Thank you for being a responsible consumer.

# About Us

## Brownells Austria

**Brownells - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories**

[www.brownells.at](http://www.brownells.at)