

# BLIZZARD SCOPE LENS COVERS - BLIZZARD LENS COVER #8 1.9-1.99" (48.3-50.6MM)

[Optics & Mounting](#) > [Optic Accessories](#) > [Scope Lens Covers](#)

## Clear, See-Thru Caps Flip Open With Just A Touch

Spring-loaded, flip-open scope covers allow fast, thru-the-scope sighting for quick, off-hand shots. Impact resistant, polymer lenses keep your scope lens dry and clear during inclement weather and ready for your next shot.



## Attributes

- Name: [BLIZZARD LENS COVER #8 1.9-1.99" \(48.3-50.6MM\)](#)
- Manufacturer: [BUTLER CREEK](#)
- Product no.: 120250008
- Mfr. No.: 70208
- Color: Black
- Model Number: 1.9-1.99" (48.3-50.6MM)
- Size: 1.919,1.96,1.998
- Delivery weight: 0.045kg
- Shipping height: 30mm
- Shipping width: 71mm
- Shipping length: 122mm
- UPC: 051525702085

# Table of Contents

- Startpage
- BLIZZARD SCOPE LENS COVERS SAFETY INSTRUCTIONS
- About Us

# BLIZZARD SCOPE LENS COVERS SAFETY INSTRUCTIONS

## Introduction

Thank you for choosing the BLIZZARD SCOPE LENS COVERS. These lens covers are designed to provide optimal protection for your scope lenses while ensuring quick access for offhand shooting. This guide contains essential safety instructions and usage guidelines to ensure your safe and effective use of the product.

## General Safety Guidelines

- Always ensure that the scope covers are properly secured when not in use to prevent accidental damage or loss.
- Inspect the lens covers for any signs of damage before each use. Do not use if damaged.
- Keep the product out of reach of children and vulnerable individuals to prevent accidental injury.
- Avoid exposing the lens covers to extreme temperatures or direct sunlight for prolonged periods.
- If you experience any issues with the product, discontinue use immediately and seek assistance.

## Specific Safety Precautions for Use

- Ensure that the scope covers are compatible with your specific scope size before installation.
- Use the lens covers only for their intended purpose; do not modify or attempt to repair them.
- When flipping open the lens covers, ensure that your hands are clear of the moving parts to avoid pinching.
- In inclement weather, regularly check that the lens covers are functioning properly to maintain visibility.
- If you notice any fogging or moisture inside the lens covers, remove them immediately and dry the lenses before use.

## Instructions for Installation and Usage

### Installation

1. Identify the appropriate size lens cover for your scope (1.91.99 inches / 48.350.6 mm).
2. Align the lens cover with the scope lens and gently press down until it clicks into place.
3. Ensure that the cover is securely attached and does not obstruct the lens.

### Usage

1. To open the lens cover, press the release mechanism to flip it open.
2. Aim through the scope and take your shot as needed.
3. After use, close the lens cover to protect the lens from dust and moisture.
4. Store the scope with the lens covers attached when not in use to prolong their lifespan.

## Disposal Instructions

- Dispose of the product in accordance with local waste management regulations.
- Do not dispose of lens covers in general household waste if they are damaged or contain hazardous materials.
- Consider recycling the product if applicable; check with local recycling facilities for guidance.

## Contact Information for Further Support

For any questions or concerns regarding the BLIZZARD SCOPE LENS COVERS, please refer to the manufacturer's

website or contact their customer support team for assistance.

Thank you for your attention to these safety instructions. Enjoy your shooting experience with the BLIZZARD SCOPE LENS COVERS!

# About Us

## Brownells Austria

**Brownells - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories**

[www.brownells.at](http://www.brownells.at)