

BLIZZARD SCOPE LENS COVERS - BUTLER CREEK BLIZZARD LENS COVER #9 2.0-2.10" (50.8-53.3MM)

[Optics & Mounting](#) > [Optic Accessories](#) > [Scope Lens Covers](#)

Clear, See-Thru Caps Flip Open With Just A Touch

Spring-loaded, flip-open scope covers allow fast, thru-the-scope sighting for quick, off-hand shots. Impact resistant, polymer lenses keep your scope lens dry and clear during inclement weather and ready for your next shot.



Attributes

- Name: [BUTLER CREEK BLIZZARD LENS COVER #9 2.0-2.10" \(50.8-53.3MM\)](#)
- Manufacturer: [BUTLER CREEK](#)
- Product no.: 120250009
- Mfr. No.: 70209
- Colour: Black
- Model Number: 2.0-2.10" (50.8-53.3MM)
- Size: 2.043,2.1
- Delivery weight: 0.032kg
- Shipping height: 38mm
- Shipping width: 71mm
- Shipping length: 122mm
- UPC: 051525702092

Table of Contents

- Startpage
- BLIZZARD SCOPE LENS COVERS SAFETY INSTRUCTIONS
- About Us

BLIZZARD SCOPE LENS COVERS SAFETY INSTRUCTIONS

Introduction

Thank you for choosing the BLIZZARD SCOPE LENS COVERS by BUTLER CREEK. These scope covers are designed to provide protection for your scope lens while ensuring quick access during use. This safety instruction guide is intended to help you use the product safely and effectively while complying with the EU General Product Safety Regulation (GPSR).

General Safety Guidelines

- Always inspect the scope covers before use to ensure they are in good condition.
- Ensure that the product is used only for its intended purpose.
- Keep the product out of reach of children to avoid accidental use or injury.
- In case of any malfunction or damage, discontinue use immediately and seek assistance.
- Be aware of your surroundings when using the scope covers to avoid accidents.

Specific Safety Precautions for Use

- Do not force the flipopen mechanism; it should operate smoothly without excessive pressure.
- Ensure that the polymer lenses are clean and free from debris before use to maintain visibility.
- Avoid exposing the scope covers to extreme temperatures or direct sunlight for prolonged periods, as this may affect the material.
- If you notice any cracks or damage to the lens covers, do not use them and contact support for further assistance.
- Always ensure your firearm is pointed in a safe direction when using the scope for sighting.

Instructions for Installation and Usage

1. Installation:

- Identify the correct size of the lens covers for your scope (2.02.10 inches or 50.853.3 mm).
- Align the covers with the scope lens and press firmly until they snap into place.
- Ensure a secure fit to prevent any moisture or debris from entering the scope.

2. Usage:

- To open the scope covers, gently flip them open using the springloaded mechanism.
- Ensure that the covers are fully retracted before aiming or shooting.
- After use, close the lens covers to protect the scope from environmental elements.

Disposal Instructions

- Dispose of the product in accordance with local regulations.
- Do not dispose of in household waste; check for recycling options where applicable.
- If the product is damaged beyond repair, contact your local waste management facility for proper disposal methods.

Contact Information for Further Support

For any inquiries regarding safety or product issues, please reach out to the designated EU contact point

provided by the manufacturer.

By following these safety instructions, you can ensure a safe and enjoyable experience with your BLIZZARD SCOPE LENS COVERS. Thank you for your attention to safety and compliance.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk