

# SPORTING CLAYS SPEED WRENCH - CARLSONS SPORTING CLAY SPEED WRENCH 20 GAUGE

[Gunsmith Tools](#) > [Shotgun Tools](#) > [Choke Tube Wrenches](#)

## Speed Handle Makes Changing Tubes Fast

Crank and handle provide both speed and leverage for quickly removing choke tubes. Large, easy-to-grip knob expands the vinyl, non-marking gripping surface that's inserted into the tube.



## Attributes

- Name: [CARLSONS SPORTING CLAY SPEED WRENCH 20 GAUGE](#)
- Manufacturer: [CARLSONS](#)
- Product no.: 155102020
- Mfr. No.: 06602
- Gauge: 20 Gauge
- Weapon type: Universal Shotguns
- Delivery weight: 0.091kg
- Shipping height: 20mm
- Shipping width: 89mm
- Shipping length: 180mm
- UPC: 723189066024

## Item details

Made in USA

# Table of Contents

- Startpage
- SPORTING CLAYS SPEED WRENCH Safety Instruction Guide
- About Us

# **SPORTING CLAYS SPEED WRENCH Safety Instruction Guide**

## **Introduction**

Thank you for choosing the Carlson's Sporting Clay Speed Wrench designed for 20 gauge shotguns. This tool is engineered to provide speed and leverage for quickly removing choke tubes. To ensure safe and effective use, please read this safety instruction guide carefully.

## **General Safety Guidelines**

- Follow all safety instructions provided in this guide.
- Ensure the wrench is used only for its intended purpose.
- Keep the product out of reach of children and vulnerable individuals.
- Regularly inspect the wrench for any signs of damage or wear before use.
- Report any unsafe conditions or incidents to the appropriate authorities.
- Stay informed about product recalls through the EU's Safety Gate platform.

## **Specific Safety Precautions for Use**

- Always ensure the shotgun is unloaded before attempting to use the speed wrench.
- Use the wrench only on compatible choke tubes to avoid damage.
- Do not force the wrench if it does not fit; check compatibility first.
- Avoid using excessive force when removing or installing choke tubes to prevent injury or damage.
- Store the wrench in a safe, dry place when not in use to maintain its condition.

## **Instructions for Installation and Usage**

### **1. Preparation:**

- Ensure the shotgun is completely unloaded.
- Identify the choke tube you wish to remove or install.

### **2. Using the Speed Wrench:**

- Grasp the large, easytogrip knob firmly.
- Align the vinyl, nonmarking gripping surface of the wrench with the choke tube.
- Turn the wrench counterclockwise to remove the choke tube or clockwise to install it.
- Use smooth, steady pressure; do not apply excessive force.

### **3. PostUse:**

- After use, clean the wrench if necessary and store it in a safe location.
- Regularly check for any wear or damage and replace if needed.

## **Disposal Instructions**

- Dispose of the product responsibly and in accordance with local regulations.
- If the wrench is damaged beyond use, consider recycling materials where applicable.
- Do not dispose of the wrench in regular household waste.

## **Contact Information for Further Support**

For any questions or concerns regarding the product, please refer to the manufacturer or seek assistance through the appropriate channels.

By adhering to these safety instructions, you can ensure a safe and effective experience with your Carlson's Sporting Clay Speed Wrench. Thank you for your attention to safety.

# About Us

## Brownells UK

### **Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories**

Unit 1, Laughing Dog Industrial Estate  
London Road  
Rugby  
Warwickshire  
CV23 9LP

[www.brownells.co.uk](http://www.brownells.co.uk)