

RUGER® 10/22® SPEED BOLT RELEASE - CLARK RUGER® 10/22® SPEED BOLT RELEASE

[Home](#)

Pull Back, Release & The Bolt Slams Home

Does away with the time consuming, clumsy, two-hand factory release. You get faster reloads, and back on target sooner. Drop-in part requires no permanent modifications.



Attributes

- Name: [CLARK RUGER® 10/22® SPEED BOLT RELEASE](#)
- Manufacturer: [CLARK CUSTOM](#)
- Product no.: 181377005
- Mfr. No.: CLK748
- Make: Ruger
- Model: 10/22
- Delivery weight: 0.091kg
- Shipping height: 13mm
- Shipping width: 79mm
- Shipping length: 150mm

Item details

Made in USA

US export classification: 0A501.x

Table of Contents

- Startpage
- RUGER® 10/22® SPEED BOLT RELEASE Safety Instruction Guide
- About Us

RUGER® 10/22® SPEED BOLT RELEASE Safety Instruction Guide

Introduction

Thank you for choosing the RUGER® 10/22® SPEED BOLT RELEASE by CLARK CUSTOM. This product enhances your shooting experience by providing faster reloads and improved target acquisition. To ensure your safety and the safety of others, please read this guide carefully before installation and use.

General Safety Guidelines

- Always treat firearms as if they are loaded.
- Keep the firearm pointed in a safe direction at all times.
- Ensure that the area is clear of people and obstacles before using the firearm.
- Store the firearm and ammunition in a secure place, out of reach of children and unauthorized users.
- Regularly inspect the product for wear or damage. Do not use if damaged.
- Always follow the manufacturer's instructions for use and maintenance.

Specific Safety Precautions for Use

- This product is designed for use with the Ruger 10/22 rifle only. Do not attempt to use it with any other firearm.
- Ensure that the firearm is unloaded before installation of the SPEED BOLT RELEASE.
- Do not attempt to modify the SPEED BOLT RELEASE or the firearm in any way that may compromise safety.
- Be aware of your surroundings and ensure that you are in a safe environment when using the firearm.
- Never place your finger on the trigger until you are ready to shoot.

Instructions for Installation and Usage

1. Installation:

- Ensure the firearm is unloaded and pointed in a safe direction.
- Remove the factory bolt release from the firearm according to the manufacturer's instructions.
- Insert the RUGER® 10/22® SPEED BOLT RELEASE into the appropriate slot.
- Ensure that the SPEED BOLT RELEASE is securely in place and functions properly before use.

2. Usage:

- When ready to reload, use the SPEED BOLT RELEASE to quickly release the bolt.
- Practice safe handling techniques while reloading and shooting.
- After use, ensure the firearm is cleared and stored safely.

Disposal Instructions

- Dispose of the product in accordance with local regulations.
- If the product is damaged or no longer usable, do not discard it in regular trash. Instead, contact your local waste management facility for proper disposal methods.

Contact Information for Further Support

For any inquiries regarding safety, installation, or usage of the RUGER® 10/22® SPEED BOLT RELEASE, please

refer to the manufacturer's website or contact their customer service directly.

By following these safety instructions, you can enjoy the benefits of the RUGER® 10/22® SPEED BOLT RELEASE while ensuring your safety and the safety of others. Thank you for prioritizing safety in your shooting activities.

About Us

Brownells Austria

Brownells - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

www.brownells.at