

DRIVE HANDLE - BROWNELLS FLEX-HEAD DRIVE HANDLE, 10-1/2" L, 1/2" SQUARE DRIVE, CHROME

[Gunsmith Tools](#) > [General Gunsmith Tools](#) > [Wrenches](#) > [General Wrenches](#)

Use with AR-15/M16 Combination Wrench to loosen the barrel nut and remove barrel. Long enough to provide ample leverage.



Attributes

- Name: [BROWNELLS FLEX-HEAD DRIVE HANDLE, 10-1/2" L, 1/2" SQUARE DRIVE, CHROME](#)
- Manufacturer: [BROWNELLS](#)
- Product no.: 221141600
- Mfr. No.: PTW32118
- Style: Drive Handles
- Delivery weight: 0.431kg
- Shipping height: 13mm
- Shipping width: 38mm
- Shipping length: 290mm
- UPC: 039564321184

Table of Contents

- Startpage
- Safety Instruction Guide for DRIVE HANDLE BROWNEllS FLEXHEAD DRIVE HANDLE
- About Us

Safety Instruction Guide for DRIVE HANDLE BROWNELLS FLEXHEAD DRIVE HANDLE

Introduction

Thank you for choosing the DRIVE HANDLE BROWNELLS FLEXHEAD DRIVE HANDLE. This guide provides essential safety instructions and usage guidelines to ensure your safety and the proper functioning of the product. Please read this manual carefully before use.

General Safety Guidelines

- Always use the drive handle in accordance with the manufacturer's instructions to prevent accidents.
- Inspect the drive handle for any damage before each use. Do not use if damaged.
- Keep the drive handle out of reach of children and vulnerable individuals.
- Ensure that the work area is clean and welllit to avoid accidents during use.
- Wear appropriate personal protective equipment (PPE) such as safety glasses and gloves when using the drive handle.
- Do not use the drive handle for any purpose other than intended.

Specific Safety Precautions for Use

- Ensure the AR15/M16 Combination Wrench is securely attached to the drive handle before use.
- Use the drive handle on compatible components only; do not attempt to use it on incompatible tools or parts.
- Apply force gradually and evenly to avoid slipping or losing control of the tool.
- Avoid overextending your reach while using the drive handle to maintain balance and control.
- If you experience resistance while loosening or tightening, stop and reassess the situation to avoid damage or injury.

Instructions for Installation and Usage

1. Preparation:

- Gather all necessary tools including the AR15/M16 Combination Wrench and the DRIVE HANDLE.
- Clear the work area of any obstacles and ensure proper lighting.

2. Attaching the Wrench:

- Insert the AR15/M16 Combination Wrench into the socket of the drive handle.
- Ensure it is securely fitted and does not wobble.

3. Using the Drive Handle:

- Position the wrench on the barrel nut or the component you wish to loosen.
- Firmly grip the handle and apply steady pressure in the counterclockwise direction to loosen.
- If tightening, apply pressure in the clockwise direction.

4. PostUse Care:

- After use, clean the drive handle with a dry cloth to remove any debris or residue.
- Store the drive handle in a dry place, away from moisture and extreme temperatures.

Disposal Instructions

- When the DRIVE HANDLE is no longer usable, dispose of it in accordance with local regulations.
- Do not dispose of the handle in general waste if it is made of materials that can be recycled. Check local recycling guidelines.

Contact Information for Further Support

For any inquiries or concerns regarding the DRIVE HANDLE BROWNELLS FLEXHEAD DRIVE HANDLE, please refer to the manufacturer's contact point provided with the product packaging.

Conclusion

By following these safety guidelines and instructions, you can ensure safe and effective use of the DRIVE HANDLE BROWNELLS FLEXHEAD DRIVE HANDLE. Always prioritize safety and do not hesitate to seek support if needed. Thank you for your attention to these important instructions.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk