

DRUM SANDER MANDREL - DREMEL #407 DRUM SANDER

[Gunsmith Tools](#) > [Power Tools & Accessories](#) > [Drum Sanders](#)

Make The Most Of your Hand-Held Tools

½" dia. For use with #408, #432 and other ½" sander bands.



Attributes

- Name: [DREMEL #407 DRUM SANDER](#)
- Manufacturer: [DREMEL](#)
- Product no.: 257400407
- Mfr. No.: 5000407
- Delivery weight: 0.009kg
- Shipping height: 5mm
- Shipping width: 46mm
- Shipping length: 84mm
- UPC: 080596004071

Table of Contents

- Startpage
- Safety Instruction Guide for DRUM SANDER MANDREL DREMEL #407 DRUM SANDER
- About Us

Safety Instruction Guide for DRUM SANDER MANDREL DREMEL #407 DRUM SANDER

Introduction

Thank you for choosing the DRUM SANDER MANDREL DREMEL #407 DRUM SANDER. This guide provides essential safety instructions and guidelines to ensure safe and effective use of this product. Please read this guide carefully before using the drum sander to avoid any accidents or injuries.

General Safety Guidelines

- Always use the drum sander according to the manufacturer's instructions.
- Inspect the drum sander and its components before each use for any signs of damage or wear.
- Keep your work area clean and welllit to avoid accidents.
- Ensure that all safety guards and devices are in place and functioning properly before use.
- Use personal protective equipment (PPE) such as safety goggles, dust masks, and hearing protection as needed.
- Keep hands and other body parts away from moving parts during operation.
- Ensure that the drum sander is securely attached to the appropriate tool before use.
- Do not use the drum sander for any purpose other than its intended use.

Specific Safety Precautions for Use

- Only use the drum sander with compatible sanding bands (#408, #432, and other $\frac{1}{2}$ " sander bands).
- Do not exceed the maximum RPM rating of the drum sander.
- Avoid using the drum sander in wet or damp conditions.
- Keep the drum sander away from flammable materials and liquids.
- Do not leave the drum sander unattended while it is running.
- If the drum sander becomes overloaded or stalls, turn it off immediately and disconnect it from the power source.
- Allow the drum sander to come to a complete stop before changing sanding bands or making adjustments.

Instructions for Installation and Usage

1. Installation:

- Ensure the power tool you are using is turned off and unplugged.
- Select a compatible sanding band ($\frac{1}{2}$ " diameter) and slide it onto the mandrel.
- Tighten the sanding band securely to prevent it from coming loose during operation.
- Attach the mandrel to your power tool according to the manufacturer's instructions.

2. Usage:

- Plug in your power tool and switch it on.
- Hold the tool firmly with both hands and maintain a stable stance.
- Gently bring the drum sander into contact with the workpiece, applying light pressure.
- Move the drum sander in a controlled manner to achieve the desired finish.
- After use, turn off the power tool and unplug it before making any adjustments or changing sanding bands.

Disposal Instructions

- Dispose of the drum sander and any used sanding bands in accordance with local regulations.
- Do not dispose of electrical components in regular household waste.
- Consider recycling options for the product and packaging materials where available.

Conclusion

By following these safety instructions and guidelines, you can ensure a safe and effective experience while using the DRUM SANDER MANDREL DREMEL #407 DRUM SANDER. Always prioritize safety and do not hesitate to seek assistance if you have any concerns or questions. Thank you for choosing DREMEL.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk