

CZ 527 16MM HD PICATINNY SCOPE MOUNT - EGW CZ 527 16MM 1-PIECE PICATINNY BASE 0 MOA

[Optics & Mounting](#) > [Rings, Mounts & Bases](#) > [Rifle Bases](#)

Picatinny cross slots run the full length of the rail, which gives the shooter flexibility when mounting scope rings and other accessories. EGW one-piece scope mounts are the obvious choice for hunters and tactical shooters alike. This mount is a Picatinny-style base and compatible with Picatinny or Weaver scope rings. EGW machines these in their shop using one of their machining centers. After machining, the mounts are tumbled, sand blasted, and Type III anodized for long lasting durability. Recommend: 0 MOA -if shooting 0-500 yards 20 MOA -if shooting 500-1000 yards When zeroing your rifle with a 20 MOA mount, EGW recommends zeroing at 200 yards. Installation: EGW recommends 20 inch lbs of torque and a drip of blue loctite (loctite is sold separately). The entire mount and accessories (from the mounting screws and wrench down to the packaging) are made in the USA.



Attributes

- Name: [EGW CZ 527 16MM 1-PIECE PICATINNY BASE 0 MOA](#)
- Manufacturer: [EGW](#)
- Product no.: 296000762
- Mfr. No.: 80928
- Colour: Black
- Elevation: 0 MOA
- Material: Aluminum
- Model: 527
- Number of Bases: 1-Piece
- Style: Picatinny Rail
- Weapon type: CZ
- Delivery weight: 0.109kg
- Shipping height: 25mm
- Shipping width: 89mm
- Shipping length: 229mm
- UPC: 841370115990

Item details

Made in USA

Table of Contents

- Startpage
- Safety Instruction Guide for CZ 527 16MM HD Picatinny Scope Mount
- About Us

Safety Instruction Guide for CZ 527 16MM HD Picatinny Scope Mount

Introduction

Thank you for choosing the CZ 527 16MM HD Picatinny Scope Mount by EGW. This guide provides essential safety instructions and information for the proper use, installation, and disposal of the product. Your safety is our priority, and it is crucial to follow these guidelines to ensure safe use and compliance with the EU General Product Safety Regulation (GPSR).

General Safety Guidelines

- **Product Safety:** Ensure safe use of the scope mount by following all instructions. This product is designed for nonfood use and must be handled with care.
- **Enhanced Recalls:** Stay informed about product recalls. If you receive notice of a recall, follow the instructions provided for a remedy.
- **Online Shopping:** If purchased online, ensure that the retailer complies with safety requirements equivalent to those in physical stores.
- **Special Consumer Focus:** This product is not intended for children. Ensure it is kept out of reach of minors.
- **EU Contact Point:** For safety inquiries, refer to the product packaging or retailer for guidance on contacting the appropriate EU-based support.
- **Rapid Alerts:** Monitor the EU's Safety Gate platform for updates on unsafe products.

Specific Safety Precautions for Use

- **Inspection:** Before use, inspect the scope mount for any signs of damage or defects. Do not use if damaged.
- **Compatibility:** Ensure that the scope mount is compatible with your firearm and accessories. Use only Picatinny or Weaver scope rings.
- **Installation:** Follow installation instructions carefully to avoid improper mounting, which could lead to accidents or equipment failure.
- **Torque Specifications:** Apply the recommended torque of 20 inch lbs when securing the mount. Overtightening may cause damage.
- **Loctite Usage:** Use a drop of blue Loctite on mounting screws to prevent loosening during use. Loctite is sold separately.
- **Shooting Distance:** For optimal performance, use the appropriate MOA setting based on your shooting distance:
 - 0 MOA for shooting 0500 yards
 - 20 MOA for shooting 5001000 yards
- **Zeroing:** When using a 20 MOA mount, zero your rifle at 200 yards as recommended by EGW.

Instructions for Installation and Usage

1. Preparation:

- Gather all necessary tools, including a torque wrench and a drop of blue Loctite.
- Ensure the firearm is unloaded and pointed in a safe direction.

2. Mounting the Scope:

- Align the Picatinny scope mount with the rail on your firearm.
- Insert the mounting screws through the mount into the rail.

- Handtighten the screws to secure the mount in place.

3. Securing the Mount:

- Using a torque wrench, tighten the screws to the recommended 20 inch lbs.
- Apply a drop of blue Loctite on each screw to secure them.

4. Installing Scope Rings:

- Attach the Picatinny or Weaver scope rings to the mount according to the manufacturer's instructions.
- Ensure the rings are securely tightened.

5. Final Check:

- Doublecheck all screws and fittings to ensure everything is secure before using the firearm.

Disposal Instructions

- **Disposal of Product:** When the scope mount has reached the end of its life or is no longer needed, dispose of it in accordance with local regulations.
- **Recycling:** If possible, recycle the aluminum material to minimize environmental impact.

Contact Information for Further Support

For any questions or concerns regarding the CZ 527 16MM HD Picatinny Scope Mount, please refer to the retailer from whom you purchased the product for assistance.

By following these guidelines, you can ensure the safe and effective use of your CZ 527 16MM HD Picatinny Scope Mount. Thank you for prioritizing safety and compliance with the EU General Product Safety Regulation.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk