

SHOTGUN SLING MOUNT - GG&G REM FRONT MOUNT

[Shotgun Parts](#) > [Stock & Forend Parts](#) > [Buttstock Hardware](#) > [Sling Swivel Components](#)

Allows Smooth, Unrestricted Sling Movement

Designed for tactical operations, these mounts place the rear sling attachment point in front of the operator, so you can quickly shoulder your weapon without getting tangled. Allows single point sling attachment, or use with a front sling mount for two-point sling installation. Loop accepts slings up to 1 $\frac{1}{4}$ " wide. Rear Mount installs directly behind receiver, in front of buttstock. Precision machined from aluminum billet, then hardcoat anodized matte black. Right hand model for Remington 870, 1100, and 11-87 positions sling on left side of stock. Ambidextrous model for Remington 870, 1100, and 11-87 accepts HK-style clasps and other clip-on sling fasteners. Rem Front Mount positions the sling on the right side for Remington shotguns with external retention type magazine caps.



Attributes

- Name: [GG&G REM FRONT MOUNT](#)
- Manufacturer: [GG&G](#)
- Product no.: 336000009
- Mfr. No.: GGG-1084
- Colour: Black
- Material: Steel
- Model: 11-87,1100,870
- Style: Shotgun Mount
- Weapon type: Remington
- Delivery weight: 0.023kg
- Shipping height: 6mm
- Shipping width: 82mm
- Shipping length: 96mm
- UPC: 813157000416

Item details

Made in USA

Table of Contents

- Startpage
- Consumer Safety Instruction Guide for SHOTGUN SLING MOUNT GG&G REM FRONT MOUNT
- About Us

Consumer Safety Instruction Guide for SHOTGUN SLING MOUNT GG&G REM FRONT MOUNT

Introduction

Thank you for choosing the SHOTGUN SLING MOUNT GG&G REM FRONT MOUNT. This product is designed to enhance your tactical operations by providing a secure and efficient sling attachment point. To ensure your safety and the proper use of this product, please read and follow the guidelines outlined in this instruction guide.

General Safety Guidelines

- **Product Safety:** This product is designed to meet safety standards for nonfood items. Ensure that you use it according to the provided instructions.
- **Enhanced Recalls:** Stay informed about any product recalls or safety notices. If you receive a recall notice, follow the instructions provided.
- **Online Shopping Safety:** If purchased online, ensure that the retailer complies with safety requirements similar to those of physical stores.
- **Special Consumer Focus:** Extra caution should be taken if this product is used by or around vulnerable groups, including children.
- **EU Contact Point:** For safety inquiries, refer to the EU-based contact information provided by the retailer or manufacturer.
- **Rapid Alerts:** Regularly check the EU's Safety Gate platform for updates on unsafe products.

Specific Safety Precautions for Use

- **Avoid Modifications:** Do not alter or modify the sling mount. Modifications can compromise safety and functionality.
- **Inspect Before Use:** Always inspect the sling mount for any signs of wear or damage before each use. Do not use if damaged.
- **Proper Sling Attachment:** Ensure that the sling is properly attached to prevent accidental detachment during use.
- **Use Appropriate Slings:** Only use slings that are compatible with the mount and do not exceed the width specification of 1 1/4 inches.
- **Follow Manufacturer Instructions:** Adhere strictly to the installation and usage instructions provided by the manufacturer.

Instructions for Installation and Usage

1. Installation of Rear Mount:

- Locate the receiver on your shotgun.
- Position the rear mount directly behind the receiver, in front of the buttstock.
- Securely attach the rear mount using the provided hardware.
- Ensure it is tightened to prevent movement during use.

2. Installation of Front Mount:

- Identify the location for the front mount on your shotgun, ensuring it is compatible with the external retention magazine cap.
- Align the front mount and attach it securely using the provided hardware.
- Confirm that it is securely fastened to prevent any slippage.

3. Sling Attachment:

- For singlepoint sling attachment, connect the sling to the rear mount.
- For twopoint sling installation, connect the sling to both the rear mount and the front mount.
- Verify that the sling is properly secured and can support the weight of the shotgun.

4. Usage:

- When shouldering the weapon, ensure that the sling does not become tangled or obstruct your movement.
- Practice shouldering the weapon with the sling attached to familiarize yourself with its operation.

Disposal Instructions

- **Environmental Considerations:** Dispose of the product in accordance with local regulations concerning aluminum and steel materials.
- **Recycling:** If possible, recycle the product to minimize environmental impact.
- **Safety Precautions:** When disposing of the product, ensure that it is not accessible to children or pets.

Contact Information for Further Support

For any inquiries regarding safety, installation, or product support, please refer to the contact information provided by your retailer or the manufacturer.

By following these guidelines, you can ensure the safe use of the SHOTGUN SLING MOUNT GG&G REM FRONT MOUNT. Thank you for prioritizing safety and compliance.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk