

STANDARD ADJUSTABLE BUTT PLATE - GRACO CORP STANDARD ADJUSTABLE BUTT PLATE SILVER ALUMINUM

[Rifle Parts](#) > [Stock Parts](#) > [Butt Plate Parts](#) > [Butt Plate Components](#)

Adjusts For Length, Drop and Rotation

Three-way adjustments for perfect gun fit, higher scores and improved shooting comfort. Base plate mounts to gun, your pad mounts to pad plate and the threaded tube provides a total of 1-1/8" in/out adjustment. Make full turns or stop the rotation anywhere in 360° and lock with the socket head set screws. Slotted top plate allows 1½" vertical adjustment. Slide a Breako Recoil Reducer into the tube for a neat, compact installation. Combine with Graco's Adjustable Comb Hardware to make your own "Try Stock".



Attributes

- Name: [GRACO CORP STANDARD ADJUSTABLE BUTT PLATE SILVER ALUMINUM](#)
- Manufacturer: [GRACO CORP](#)
- Product no.: 352150100
- Mfr. No.: 575S
- Finish: Silver
- Material: Aluminum
- Weapon type: Universal Rifles
- Delivery weight: 0.249kg
- Shipping height: 58mm
- Shipping width: 61mm
- Shipping length: 160mm

Item details

Made in USA

Table of Contents

- Startpage
- Safety Instructions for the STANDARD ADJUSTABLE BUTT PLATE
- About Us

Safety Instructions for the STANDARD ADJUSTABLE BUTT PLATE

Introduction

Thank you for choosing the STANDARD ADJUSTABLE BUTT PLATE by Graco Corp. This product is designed to enhance your shooting experience with its adjustable features. To ensure safe and effective use, please read and follow these safety instructions carefully.

General Safety Guidelines

- Ensure the product is installed correctly to avoid accidents.
- Always handle firearms with care and follow all safety regulations.
- Keep the butt plate out of reach of children and vulnerable individuals.
- Regularly inspect the butt plate for any signs of wear or damage.
- If you notice any defects or issues, discontinue use immediately and consult a professional.

Specific Safety Precautions for Use

- Do not exceed the recommended weight limit for the butt plate.
- Ensure that all adjustments are securely locked before use.
- Avoid using the butt plate in extreme weather conditions that may affect its performance.
- Use only compatible firearms with the butt plate to prevent accidents.
- Follow the manufacturer's guidelines for the installation of additional accessories.

Instructions for Installation and Usage

1. Installation

- Gather the necessary tools: a drill, screwdriver, and appropriate drill bits.
- Ensure the firearm is unloaded and pointed in a safe direction.
- Drill a 11/8" (28.6mm) hole in the stock of the firearm, centered between the attaching holes.
- Align the base plate of the butt plate with the drilled hole.
- Secure the base plate using the provided screws, ensuring it is firmly attached.
- Mount your pad to the pad plate using the threaded tube for adjustments.
- Lock the adjustments using the socket head set screws.

2. Usage

- Adjust the butt plate to achieve a comfortable fit by turning the threaded tube.
- Make full turns or stop at any point within the 360° rotation.
- Utilize the slotted top plate for 1½" vertical adjustments as needed.
- For enhanced recoil reduction, slide a Breako Recoil Reducer into the tube.

Disposal Instructions

- Dispose of the product in accordance with local regulations.
- If the butt plate is damaged beyond repair, ensure it is recycled or disposed of in an environmentally friendly manner.
- Do not dispose of the product in household waste.

Contact Information for Further Support

For any inquiries regarding safety or product issues, please consult the manufacturer's website or customer service for assistance.

By following these guidelines, you can ensure a safe and enjoyable experience with your STANDARD ADJUSTABLE BUTT PLATE. Thank you for your attention to safety.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk