

ADJUSTABLE INCLINATION MOUNT - ERATAC ADJUSTABLE INCLINATION MOUNT FOR 30MM SCOPE, LEVER SYSTEM

[Optics & Mounting](#) > [Rings, Mounts & Bases](#) > [Mount Sets](#)

New GEN-2 with lightweight lever or nut system. Up to 7% lighter. Often the range of elevation adjustment of the scope is not the adequate to compensate for the bullet drop at long ranges. This scope mount was developed to offset the missing adjustment range of the scope. The inclination of the scope mount can be adjusted individually in steps of 10 from 0 - 70 MOA. The mount and the rifle scope can remain on the rifle. Self-locking thread inserts ensure permanent and stable seating of both bolted connections. Eratac guarantee 100% repeatability and shot strength. The upper and lower part of the mount are securely connected to each other by a screw running across the hand wheel diagonally. The hinge is designed as a solid tapered joint and ensures play-free seating of the components. NEW: The mount is now also supplied with a dial in mrad/MIL. The inclination can be changed in steps of 5 between 0 - 20 mrad/MIL. A Dozen Reasons for ERATAC Mounts: Machined from solid high-grade aluminum Hard anodized, matte black Made acc. to Mil-Spec. Type III Rust-proof components 100% repeatability Immediate return to zero! Tested up to cal. .50 BMG Available in many heights for different weapons and scopes With or without inclination for long-range shooting Rings with UNIVERSAL interface for attaching various tactical accessories Clamping system manufactured acc. to NATO-STANAG 4694, compatible with Mil-Std. 1913 Locking by either safety levers or hexagonal nuts without losable parts 100% made in Germany



New GEN-2 with lightweight lever or nut system. Up to 7% lighter. Often the range of elevation adjustment of the scope is not the adequate to compensate for the bullet drop at long ranges. This scope mount was developed to offset the missing adjustment range of the scope. The inclination of the scope mount can be adjusted individually in steps of 10 from 0 - 70 MOA. The mount and the rifle scope can remain on the rifle. Self-locking thread inserts ensure permanent and stable seating of both bolted connections. Eratac guarantee 100% repeatability and shot strength. The upper and lower part of the mount are securely connected to each other by a screw running across the hand wheel diagonally. The hinge is designed as a solid tapered joint and ensures play-free seating of the components. NEW: The mount is now also supplied with a dial in mrad/MIL. The inclination can be changed in steps of 5 between 0 - 20 mrad/MIL. A Dozen Reasons for ERATAC Mounts: Machined from solid high-grade aluminum Hard anodized, matte black Made acc. to Mil-Spec. Type III Rust-proof components 100% repeatability Immediate return to zero! Tested up to cal. .50 BMG Available in many heights for different weapons and scopes With or without inclination for long-range shooting Rings with UNIVERSAL interface for attaching various tactical accessories Clamping system manufactured acc. to NATO-STANAG 4694, compatible with Mil-Std. 1913 Locking by either safety levers or hexagonal nuts without losable parts 100% made in Germany

Attributes

- Name: [ERATAC ADJUSTABLE INCLINATION MOUNT FOR 30MM SCOPE, LEVER SYSTEM](#)
- Manufacturer: [ERATAC](#)
- Product no.: 430105684

- Mfr. No.: T4073-0025
- Finish: Black
- Height: 2.24"
- Length: 5.35"
- Scope Tube Diameter: 30mm
- Style: Clamp-On
- Delivery weight: 0.44kg
- Shipping height: 61mm
- Shipping width: 88mm
- Shipping length: 203mm

Table of Contents

- Startpage
- Adjustable Inclination Mount Safety Instruction Guide
- About Us

Adjustable Inclination Mount Safety Instruction Guide

Introduction

Thank you for choosing the Eratac Adjustable Inclination Mount for your 30mm scope. This product is designed to enhance your shooting experience by providing adjustable elevation to compensate for bullet drop at long ranges. Please read this safety instruction guide carefully to ensure safe and effective use of the mount.

General Safety Guidelines

- Ensure the mount is compatible with your rifle and scope before installation.
- Always check for any visible damage or defects before use.
- Follow all local laws and regulations regarding the use of firearms and accessories.
- Keep the product out of reach of children and unauthorized users.
- Regularly inspect the mount for wear and tear, and replace it if any damage is found.
- Be aware of your surroundings when using firearms and ensure that you are in a safe shooting environment.

Specific Safety Precautions for Use

- **Installation:** Ensure that the mount is installed securely to avoid any accidents during use.
- **Adjustment:** When adjusting the inclination, do so carefully and ensure that the mount is locked in place before firing.
- **Shooting Position:** Maintain a stable shooting position to ensure accuracy and safety.
- **Cleaning:** Use appropriate cleaning materials to maintain the mount. Avoid using harsh chemicals that may damage the finish.
- **Storage:** Store the mount in a dry and secure location when not in use to prevent damage and unauthorized access.

Instructions for Installation and Usage

1. Installation:

- Ensure that the rifle is unloaded and pointed in a safe direction.
- Align the mount with the scope and rifle as per the manufacturer's specifications.
- Secure the mount using the provided screws and ensure that they are tightened properly.
- Confirm that the mount is stable and does not wobble.

2. Adjustment:

- To adjust the inclination, loosen the locking mechanism.
- Adjust the mount in 10 MOA increments from 0 to 70 MOA or in 5 mrad/MIL increments from 0 to 20 mrad/MIL as needed.
- Once the desired setting is achieved, relock the mechanism to secure the adjustment.

3. Usage:

- Fire the rifle only when you are sure of your target and what is beyond it.
- After making adjustments, perform a test shot to ensure that the scope is correctly aligned.
- If you experience any issues with the mount during use, cease firing immediately and inspect the mount.

Disposal Instructions

- Dispose of the mount according to local regulations regarding electronic and metal waste.
- If the mount is no longer usable, ensure that it is dismantled safely to prevent any potential hazards.

Contact Information for Further Support

For any inquiries regarding safety or product performance, please contact your local Eratac representative or the store where the product was purchased.

Thank you for your attention to these safety instructions. Enjoy your shooting experience with the Eratac Adjustable Inclination Mount!

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk