

RECOIL PAD - MEDIUM 1-1/8" DUAL ACTION SPORTING CLAY PAD, BLACK

[Home](#)

Soft, Genuine Sorbothane~

These pads don't just slow recoil down, they actually cut the kick dramatically by absorbing it! Made from soft, springy, Sorbothane, they end next-day-hurt, tame large caliber flinch and allow recoil-sensitive shooters to shoot in comfort. Won't ever bottom out. Grind and shape like regular pads, just don't allow heat to build up. 200 Series Dual Action Sporting Clays pad has two layers of Sorbothane for extra protection. The first layer reacts quickly to absorb initial recoil, while the second layer dissipates the remaining energy to maximize absorption. Heel is canted approximately 45° for easy shouldering from the "low gun" position. 300 Series All Purpose has a slightly concave face designed for all shooting applications. 300 Series Dual Action All Purpose pad combines the two-layer absorption properties of the 200 Series Dual Action pads with a flat back and downward-canted ends for easy shouldering in a wide variety shooting applications. 400 Series Trap has a more pronounced concave face than 300 Series for fixed-position trapshooting. 500 Series Magnum is designed for heavy recoiling guns and has a flat face and downward canted ends for easy shouldering. All pads feature solid sides, a black base, and leather-grain textured face.



Attributes

- Name: [MEDIUM 1-1/8" DUAL ACTION SPORTING CLAY PAD, BLACK](#)
- Manufacturer: [KICK-EEZ](#)
- Product no.: 440000053
- Mfr. No.: DA 202-10-M-B
- Color: Black
- Material: Polymer
- Size: Medium
- Style: Sporting Clay
- Thickness: 1-1/8"
- Delivery weight: 0.227kg
- Shipping height: 43mm
- Shipping width: 84mm
- Shipping length: 244mm
- UPC: 730412001578

Item details

Made in USA

Table of Contents

- [Startpage](#)
- [RECOIL PAD MEDIUM 11/8" DUAL ACTION SPORTING CLAY PAD, BLACK Safety Instruction Guide](#)
- [About Us](#)

RECOIL PAD MEDIUM 11/8" DUAL ACTION SPORTING CLAY PAD, BLACK Safety Instruction Guide

Introduction

Thank you for choosing the RECOIL PAD MEDIUM 11/8" DUAL ACTION SPORTING CLAY PAD. This guide provides essential safety instructions and guidelines to ensure the safe and effective use of this product. Please read this guide carefully before using the pad.

General Safety Guidelines

- Always inspect the recoil pad for any signs of damage or wear before use. Do not use if damaged.
- Ensure that the pad is properly installed on your firearm according to the installation instructions.
- Keep the recoil pad out of reach of children and vulnerable individuals when not in use.
- Use the pad only for its intended purpose, which is to reduce recoil when shooting.
- Be aware of your surroundings and ensure a safe shooting environment.
- If you experience discomfort or pain while using the pad, discontinue use immediately and consult a professional.

Specific Safety Precautions for Use

- The recoil pad is designed to absorb recoil; however, it does not eliminate it entirely. Always practice safe shooting techniques.
- Avoid exposing the pad to excessive heat, as this may affect its performance. Do not leave it in direct sunlight or near heat sources.
- Ensure that any firearm you use with the pad is suitable for your skill level and experience.
- Make sure the pad is securely attached before each use to prevent it from slipping during shooting.
- Use caution when grinding or shaping the pad, as excessive heat generated during these processes may damage it.

Instructions for Installation and Usage

1. Installation:

- Remove the existing pad from your firearm if applicable.
- Align the recoil pad with the stock of the firearm, ensuring it fits snugly.
- Secure the pad using the appropriate screws or fasteners provided with the pad.
- Check that the pad is firmly attached and does not move when pressure is applied.

2. Usage:

- Position the firearm in a comfortable shooting stance, ensuring that the pad is pressed against your shoulder.
- Aim carefully and ensure that your finger is off the trigger until you are ready to shoot.
- Fire the weapon following all standard safety protocols.
- After shooting, inspect the pad for any signs of wear or damage.

Disposal Instructions

- When the recoil pad reaches the end of its life or is no longer usable, dispose of it responsibly.
- Check local regulations for guidelines on disposing of polymer products.

- Do not simply throw the pad in regular trash if local rules require special disposal methods for such materials.

Contact Information for Further Support

For any questions or concerns regarding the safety and use of the RECOIL PAD MEDIUM 11/8" DUAL ACTION SPORTING CLAY PAD, please consult the manufacturer's website or your place of purchase for assistance.

By following these guidelines, you can ensure a safer and more enjoyable shooting experience. Thank you for your attention to safety, and happy shooting!

About Us

Brownells Austria

Brownells - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

www.brownells.at