

RIFLE PITCH SPACER - KICK-EEZ CHEEK-EEZ 1/2" PITCH SPACER PLASTIC BLACK

[Rifle Parts](#) > [Stock Parts](#) > [Butt Plate Parts](#) > [Buttstock Spacers](#)

Adjust Stock Fit Without Cutting Stock

Tapered spacers provide positive or negative pitch angle. Easily finished polymer material blends well with stocks and recoil pads. Pre-drilled, oblong slot adapts to most hole spacings.



Attributes

- Name: [KICK-EEZ CHEEK-EEZ 1/2" PITCH SPACER PLASTIC BLACK](#)
- Manufacturer: [KICK-EEZ](#)
- Product no.: 440105002
- Mfr. No.: 105-120
- Finish: Black
- Material: Plastic
- Size: 5-2/25 in.
- Delivery weight: 0.023kg
- Shipping height: 6mm
- Shipping width: 58mm
- Shipping length: 154mm
- UPC: 730412000755

Item details

Made in USA

Table of Contents

- Startpage
- Safety Instructions for RIFLE PITCH SPACER KICKEEZ CHEEKEEZ
- About Us

Safety Instructions for RIFLE PITCH SPACER KICKEEZ CHEEKEEZ

Introduction

Thank you for choosing the RIFLE PITCH SPACER KICKEEZ CHEEKEEZ. This product is designed to enhance your shooting experience by providing adjustable pitch angles for your rifle. To ensure safe and effective use, please read this safety instruction guide carefully.

General Safety Guidelines

- Always follow the manufacturer's instructions for installation and use.
- Ensure that the product is suitable for your specific rifle model.
- Regularly inspect the spacer for any signs of wear or damage before each use.
- Keep the product out of reach of children and vulnerable individuals.
- Report any unsafe conditions or incidents to the relevant authorities.
- Check for recall updates on the EU's Safety Gate platform.

Specific Safety Precautions for Use

- Hazard Identification:**
 - Improper installation may lead to instability while shooting.
 - The product may contain small parts, posing a choking hazard for children.
- Avoiding Hazards:**
 - Ensure that all screws and fittings are securely tightened before use.
 - Do not exceed the recommended pitch adjustments to maintain stability.
 - Use the product only for its intended purpose; do not modify it.

Instructions for Installation and Usage

1. Installation:

- Gather all necessary tools (e.g., screwdriver).
- Ensure the rifle is unloaded and pointed in a safe direction.
- Locate the existing mounting holes on your rifle stock.
- Align the predrilled oblong slot of the spacer with the mounting holes.
- Secure the spacer using the appropriate screws, ensuring a tight fit.
- Doublecheck the alignment and stability of the spacer before proceeding.

2. Usage:

- Adjust the pitch angle as needed by using the tapered design of the spacer.
- Regularly check the tightness of the screws during use.
- If you notice any instability or looseness, stop using the rifle immediately and inspect the spacer.

Disposal Instructions

- Dispose of the product in accordance with local regulations.
- Do not dispose of the product in regular household waste.

- If the product is damaged or no longer usable, consider recycling options available in your area.

Contact Information for Further Support

For any inquiries or concerns regarding the RIFLE PITCH SPACER KICKEEZ CHEEKEEZ, please refer to the manufacturer's contact information provided on the packaging or in the product documentation.

Thank you for your attention to these safety instructions. Enjoy your shooting experience!

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk