

RIFLE PITCH SPACER - KICK-EEZ CHEEK-EEZ 1/4" PITCH SPACER PLASTIC BLACK

[Rifle Parts](#) > [Stock Parts](#) > [Butt Plate Parts](#) > [Buttstock Spacers](#)

Adjust Stock Fit Without Cutting Stock

Tapered spacers provide positive or negative pitch angle. Easily finished polymer material blends well with stocks and recoil pads. Pre-drilled, oblong slot adapts to most hole spacings.



Attributes

- Name: [KICK-EEZ CHEEK-EEZ 1/4" PITCH SPACER PLASTIC BLACK](#)
- Manufacturer: [KICK-EEZ](#)
- Product no.: 440105003
- Mfr. No.: 105-140
- Finish: Black
- Material: Plastic
- Size: 5-2/25 in.
- Delivery weight: 0.018kg
- Shipping height: 6mm
- Shipping width: 54mm
- Shipping length: 142mm
- UPC: 730412000762

Item details

Made in USA

Table of Contents

- Startpage
- RIFLE PITCH SPACER KICKEEZ CHEEKEEZ Safety Instructions
- About Us

RIFLE PITCH SPACER KICKEEZ CHEEKEEZ Safety Instructions

Introduction

Thank you for choosing the RIFLE PITCH SPACER KICKEEZ CHEEKEEZ. This product is designed to enhance your shooting experience by providing adjustable pitch angles for your rifle. It is essential to use this product safely and correctly to ensure optimal performance and your safety.

General Safety Guidelines

- Ensure that the product is used as intended and in accordance with these instructions.
- Regularly inspect the product for any signs of wear or damage before use.
- Keep the product out of reach of children and vulnerable individuals.
- Report any unsafe products or accidents to the relevant authorities.
- Stay informed about recalls and safety updates through the EU's Safety Gate platform.

Specific Safety Precautions for Use

- Always ensure that the rifle is unloaded before installing or adjusting the spacer.
- Use appropriate tools for installation to avoid damaging the product or the rifle.
- Do not exceed the recommended pitch adjustments; improper use may lead to instability or accidents.
- Avoid using the spacer if it shows any signs of damage, such as cracks or breaks.
- Ensure that the spacer is securely attached before using the rifle.

Instructions for Installation and Usage

1. Preparation

- Gather necessary tools: screwdriver and measuring tape.
- Ensure the rifle is unloaded and placed on a stable surface.

2. Installation Steps

- Locate the existing holes on your rifle stock where the spacer will be installed.
- Align the predrilled oblong slot of the spacer with the holes on the stock.
- Use the appropriate screws (not included) to secure the spacer in place.
- Tighten the screws until the spacer is firmly attached but do not overtighten to avoid damage.

3. Adjusting the Pitch

- The tapered design allows for adjustments between a positive or negative pitch angle.
- To achieve the desired pitch, ensure the spacer is positioned correctly before securing it.
- Refer to the product specifications for the correct taper measurements.

4. Final Inspection

- Once installed, doublecheck that the spacer is securely fastened and stable.
- Test the adjustment by gently applying pressure to ensure there is no movement.

Disposal Instructions

- Dispose of the product responsibly according to local regulations.

- Recycle the plastic material if possible, or dispose of it in a designated waste facility.
- Ensure that the product is rendered unusable before disposal to prevent accidental use.

Contact Information for Further Support

For any inquiries regarding the RIFLE PITCH SPACER KICKEEZ CHEEKEEZ, please refer to the manufacturer's contact details provided in the product packaging.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk