

FLAT WIRE RECOIL SPRINGS FOR GLOCK® - ISMI 17 LB. SPRING FOR GLOCK® 17

[Handgun Parts](#) > [Recoil Parts](#) > [Recoil Springs](#)

Designed For Maximum Consistency & Reliability

CAD designed and built to Aerospace specifications from chrome silicon, corrosion resistant, stainless steel or chrome vanadium for maximum durability, consistency and reliable performance. Built to aerospace specifications; heat treated, shot peened and fully stress relieved to minimize spring set. GLOCK® RECOIL SPRINGS - Flat wire, chrome vanadium alloy,, wound to fit factory diameter guide rod of .250" or less. GLOCK® 17 fits large frame 17,17L,20,21,22,24,31,35. Factory weight is 17 lb. GLOCK® 19 fits 19,23,25,32. Factory weight is 18 lb.



Attributes

- Name: [ISMI 17 LB. SPRING FOR GLOCK® 17](#)
- Manufacturer: [ISMI](#)
- Product no.: 445000006
- Mfr. No.: GL17
- Model: 17
- Pounds: 17 lbs
- Weapon type: Glock
- Delivery weight: 0.014kg
- Shipping height: 8mm
- Shipping width: 76mm
- Shipping length: 191mm

Item details

Made in USA

Table of Contents

- Startpage
- FLAT WIRE RECOIL SPRINGS FOR GLOCK® ISMI 17 LB. SPRING FOR GLOCK® 17 Safety Instruction Guide
- About Us

FLAT WIRE RECOIL SPRINGS FOR GLOCK® ISMI 17 LB. SPRING FOR GLOCK® 17 Safety Instruction Guide

Introduction

Thank you for choosing the ISMI Flat Wire Recoil Springs for your Glock® firearm. This guide provides essential safety instructions and guidelines to ensure the safe use of this product. Please read this manual carefully before installation and use.

General Safety Guidelines

- Ensure that the recoil spring is compatible with your Glock® model. This product is designed for Glock® 17 and other compatible models.
- Always handle firearms with care and ensure they are unloaded before performing any maintenance or modifications.
- Store the recoil springs in a cool, dry place away from direct sunlight and moisture.
- Regularly inspect the recoil spring for signs of wear or damage. Replace it if any issues are detected.
- Follow all local laws and regulations regarding firearm modifications and use.

Specific Safety Precautions for Use

- Use only ISMI recoil springs with your Glock® to ensure safety and reliability.
- Never exceed the manufacturer's recommended weight specifications for your firearm.
- Avoid using the recoil spring if it shows any signs of corrosion or physical damage.
- Keep the recoil spring out of reach of children and unauthorized users.
- Always wear protective eyewear when working with firearms.

Instructions for Installation and Usage

1. Preparation:

- Ensure the firearm is unloaded and pointed in a safe direction.
- Gather necessary tools: a punch tool and a small hammer.

2. Removal of the Old Recoil Spring:

- Remove the slide from the frame of the Glock®.
- Carefully remove the old recoil spring by pushing down on the recoil spring assembly and sliding it out.

3. Installation of the New Recoil Spring:

- Take the new ISMI recoil spring and align it with the factory diameter guide rod of .250" or less.
- Insert the recoil spring onto the guide rod, ensuring it is seated properly.
- Reattach the slide to the frame of the Glock®.

4. Testing:

- After installation, perform a function check to ensure the firearm operates correctly.
- Conduct a test fire in a safe and controlled environment to verify performance.

Disposal Instructions

- Dispose of old recoil springs and any packaging materials in accordance with local regulations.
- Do not dispose of springs in a manner that may pose a risk to the environment or public safety.

Contact Information for Further Support

For any questions regarding the installation, use, or safety of the ISMI Flat Wire Recoil Springs, please refer to the manufacturer's contact information provided on the packaging or visit the official website.

By adhering to these guidelines and instructions, you can ensure the safe and effective use of your ISMI Flat Wire Recoil Springs for Glock®. Always prioritize safety and compliance with local laws when handling firearms.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk