

FLAT WIRE RECOIL SPRINGS FOR GLOCK® - ISMI 13# CERT RECOIL SPRING GLOCK 19

[Handgun Parts](#) > [Recoil Parts](#) > [Recoil Springs](#)

Designed For Maximum Consistency & Reliability

CAD designed and built to Aerospace specifications from chrome silicon, corrosion resistant, stainless steel or chrome vanadium for maximum durability, consistency and reliable performance. Built to aerospace specifications; heat treated, shot peened and fully stress relieved to minimize spring set. GLOCK® RECOIL SPRINGS - Flat wire, chrome vanadium alloy,, wound to fit factory diameter guide rod of .250" or less. GLOCK® 17 fits large frame 17,17L,20,21,22,24,31,35. Factory weight is 17 lb. GLOCK® 19 fits 19,23,25,32. Factory weight is 18 lb.



Attributes

- Name: [ISMI 13# CERT RECOIL SPRING GLOCK 19](#)
- Manufacturer: [ISMI](#)
- Product no.: 445000034
- Mfr. No.: GLC-13
- Model: 19,23,32
- Pounds: 13 lbs
- Weapon type: Glock
- Delivery weight: 0.011kg
- Shipping height: 13mm
- Shipping width: 70mm
- Shipping length: 203mm

Item details

Made in USA

Table of Contents

- [Startpage](#)
- [Safety Instruction Guide for FLAT WIRE RECOIL SPRINGS FOR GLOCK® ISMI 13# CERT RECOIL SPRING GLOCK 19](#)
- [About Us](#)

Safety Instruction Guide for FLAT WIRE RECOIL SPRINGS FOR GLOCK® ISMI 13# CERT RECOIL SPRING GLOCK 19

Introduction

Thank you for choosing the FLAT WIRE RECOIL SPRINGS FOR GLOCK® ISMI 13# CERT RECOIL SPRING GLOCK 19. This guide provides important safety information and instructions to ensure the safe use of this product. Please read this guide carefully before using the recoil springs.

General Safety Guidelines

- Ensure the product is used only for its intended purpose.
- Always check for any visible damage or wear before installation.
- Use the recoil springs in compliance with the specifications outlined in this guide.
- Store the recoil springs in a dry and safe location, away from children and unauthorized users.
- Regularly inspect the springs for signs of corrosion or deformation.

Specific Safety Precautions for Use

- Only install the recoil springs in compatible Glock models (Glock 19, 23, 32).
- Ensure the firearm is unloaded and pointed in a safe direction before installation.
- Do not exceed the recommended weight specifications for your specific Glock model.
- Avoid using the recoil springs in extreme temperatures or environments that may affect their performance.
- If you experience any malfunctions during use, discontinue use immediately and consult a qualified gunsmith.

Instructions for Installation and Usage

1. Preparation:

- Ensure the firearm is unloaded.
- Gather necessary tools (if required) for installation.

2. Installation Steps:

- Remove the existing recoil spring from the guide rod.
- Carefully install the new recoil spring onto the guide rod, ensuring it is properly seated.
- Reassemble the firearm according to the manufacturer's instructions.

3. Usage:

- Use the firearm in a safe and responsible manner, adhering to all local laws and regulations.
- Regularly clean and maintain the firearm to ensure optimal performance of the recoil springs.

Disposal Instructions

- Dispose of any damaged or worn recoil springs in accordance with local regulations.
- Do not throw recoil springs in regular household waste.
- Consider recycling options where available.

Contact Information for Further Support

For any inquiries regarding safety, installation, or product performance, please refer to the EUbased contact point provided by the manufacturer. Ensure you have the product details on hand for efficient assistance.

By following these safety guidelines and instructions, you can ensure the safe and effective use of your FLAT WIRE RECOIL SPRINGS FOR GLOCK® ISMI 13# CERT RECOIL SPRING GLOCK 19. Thank you for your attention to safety.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk