

AR-15/M16 ADJUSTABLE GAS BLOCKS - J P ENTERPRISES LOW PROFILE ADJUSTABLE GAS BLOCK .750 BORE, BLACK SS

[Rifle Parts](#) > [Gas System Parts](#) > [Gas Blocks](#)

Pressure Adjustable For Smoother Cycling

Replaces the factory front sight/gas block and allows you to tune the gas system for smoother cycling and operation. Especially critical on match and varmint rifles when shooting both factory and custom-loaded ammunition. Simple setscrew lets you control the gas flow, so you can customize the setting for each load. Hex head setscrews clamp the block securely to the barrel. Installation instructions included. Low Profile model fits under handguard on .750" barrels. Rugged, all-steel construction resists gas erosion and helps maintain rifle's weight distribution. JPGS-5B and JPGS-5S Low-Profile models have a slimmer profile to reduce weight and to fit under a wider variety of handguards.



Replaces the factory front sight/gas block and allows you to tune the gas system for smoother cycling and operation. Especially critical on match and varmint rifles when shooting both factory and custom-loaded ammunition. Simple setscrew lets you control the gas flow, so you can customize the setting for each load. Hex head setscrews clamp the block securely to the barrel. Installation instructions included. Low Profile model fits under handguard on .750" barrels. Rugged, all-steel construction resists gas erosion and helps maintain rifle's weight distribution. JPGS-5B and JPGS-5S Low-Profile models have a slimmer profile to reduce weight and to fit under a wider variety of handguards.

Attributes

- Name: [J P ENTERPRISES LOW PROFILE ADJUSTABLE GAS BLOCK .750 BORE, BLACK SS](#)
- Manufacturer: [J P ENTERPRISES](#)
- Product no.: 452000148
- Mfr. No.: JPGS-5B
- Inside Diameter: .750
- Material: Black Stainless Steel
- Style: Adjustable,Clamp,Low-Profile
- Weapon type: AR-15
- Delivery weight: 0.197kg
- Shipping height: 51mm
- Shipping width: 140mm
- Shipping length: 184mm
- UPC: 812872021478

Item details

Made in USA

US export classification: 0A501.x

Table of Contents

- Startpage
- Safety Instruction Guide for AR15/M16 Adjustable Gas Blocks
- About Us

Safety Instruction Guide for AR15/M16 Adjustable Gas Blocks

Introduction

Thank you for choosing the J P Enterprises Low Profile Adjustable Gas Block for your AR15/M16 rifle. This guide provides essential safety instructions and usage guidelines to ensure safe operation and optimal performance of your gas block. Please read this document carefully before installation and use.

General Safety Guidelines

- Ensure that the gas block is compatible with your firearm model and barrel diameter (.750").
- Always handle firearms with care and follow standard firearm safety practices.
- Inspect the gas block for any visible damage before installation.
- Keep the gas block and all firearm components out of reach of children.
- If you are unsure about any aspect of installation or use, consult a qualified gunsmith.

Specific Safety Precautions for Use

• Installation Precautions:

- Use the appropriate tools as specified in the installation instructions.
- Do not overtighten setscrews, as this may damage the gas block or barrel.

• Operational Precautions:

- Regularly check for gas leaks after installation and during use.
- If you notice any unusual sounds or malfunctions, cease operation immediately and inspect the gas block.

• Ammunition Safety:

- Use only recommended ammunition types for your gas block and firearm.
- Be aware of the differences in gas flow when using factory versus customloaded ammunition.

Instructions for Installation and Usage

1. Preparation:

- Ensure the firearm is unloaded and pointed in a safe direction.
- Gather necessary tools: Allen wrench for setscrews, cleaning cloth, and any other tools specified in the installation manual.

2. Installation Steps:

- Remove the factory front sight/gas block from the barrel.
- Clean the barrel area where the new gas block will be installed.
- Position the adjustable gas block on the barrel, ensuring it is aligned correctly.
- Secure the gas block using the hex head setscrews. Tighten them evenly to avoid misalignment.
- Adjust the setscrew to control the gas flow according to your preferences.
- Reinstall the handguard, ensuring it fits properly over the gas block.

3. PostInstallation Check:

- After installation, conduct a function check by cycling the action of the firearm without ammunition.
- Inspect the gas block for proper alignment and secure attachment.

4. Usage:

- Regularly monitor the performance of the gas block during shooting sessions.
- Adjust the gas settings as needed based on the performance of different ammunition types.

Disposal Instructions

- When disposing of the gas block, comply with local regulations regarding metal waste.
- Do not dispose of the gas block in regular household waste.
- If the gas block is damaged beyond repair, consider recycling it at a designated metal recycling facility.

Contact Information for Further Support

For additional support or inquiries regarding the safety and operation of your gas block, please refer to the manufacturer's contact information provided with your product packaging.

By following these guidelines and precautions, you can ensure the safe and effective use of your J P Enterprises Low Profile Adjustable Gas Block. Thank you for prioritizing safety in your firearm practices.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk