

TWO CHERRIES CHISEL - BROWNELLS CHISEL, STRAIGHT WITH WOOD HANDLE, 4MM

[Gunsmith Tools](#) > [Stock Work & Finishing](#) > [Wood Carving Chisels](#)

Forged-Steel Holds Its Edge; Steel-Hooped, Hornbeam Handles Won't Split

German steel chisels are hardened to Rc 61 for superior strength and sharpness. Hornbeam handles have steel hoops to prevent splitting. Final honing is required prior to use.



Attributes

- Name: [BROWNELLS CHISEL, STRAIGHT WITH WOOD HANDLE, 4MM](#)
- Manufacturer: [BROWNELLS](#)
- Product no.: 541000005
- Mfr. No.: 5100104
- Delivery weight: 0.045kg
- Shipping height: 8mm
- Shipping width: 13mm
- Shipping length: 206mm
- UPC: 050806023130

Table of Contents

- Startpage
- TWO CHERRIES CHISEL BROWNELLS 4MM STRAIGHT CHISEL Safety Instructions
- About Us

TWO CHERRIES CHISEL BROWNELLS 4MM STRAIGHT CHISEL Safety Instructions

Introduction

Thank you for choosing the TWO CHERRIES CHISEL BROWNELLS 4MM STRAIGHT CHISEL. This guide provides essential safety information to ensure the safe use of this product. Please read and follow these instructions carefully to minimize risks and maximize your experience.

General Safety Guidelines

- Ensure that the chisel is used only for its intended purpose—wood carving.
- Always inspect the chisel before use for any signs of damage or wear.
- Keep the chisel out of reach of children and vulnerable individuals.
- Use personal protective equipment (PPE) such as safety glasses and gloves to protect against injury.
- Store the chisel in a safe, dry place when not in use.
- Follow local regulations regarding the disposal of tools and materials.

Specific Safety Precautions for Use

- Always use the chisel with a stable work surface.
- Avoid applying excessive force when using the chisel; let the tool do the work.
- Keep your hands and body clear of the cutting edge while using the chisel.
- Do not use the chisel if you are tired or under the influence of drugs or alcohol.
- Ensure that the workpiece is securely clamped or held in place to prevent movement.
- Do not leave the chisel unattended while in use.

Instructions for Installation and Usage

1. **Preparation:** Before using the chisel, ensure it is clean and free of debris.
2. **Honing:** Final honing of the chisel is required prior to use. Use a sharpening stone or honing guide to achieve the desired sharpness.
3. **Grip:** Hold the chisel firmly by the handle, ensuring a secure grip.
4. **Positioning:** Position the chisel at the desired angle against the workpiece.
5. **Cutting Technique:**
 - Start with light pressure and gradually increase as needed.
 - Apply controlled movements to avoid slipping or losing control.
6. **PostUse Care:** After use, clean the chisel with a dry cloth and store it properly.

Disposal Instructions

- Dispose of the chisel in accordance with local waste disposal regulations.
- If the chisel is damaged beyond repair, ensure it is disposed of safely to prevent injury to others.

Contact Information for Further Support

For any safety inquiries or further assistance, please refer to the manufacturer's contact details provided with the product packaging.

By following these safety instructions, you can ensure a safe and enjoyable experience with your TWO CHERRIES CHISEL BROWNELLS 4MM STRAIGHT CHISEL. Always prioritize safety and be aware of your surroundings while using this tool.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk