

ANTI CANT DEVICE - MOUNTING SOLUTIONS PLUS 1" BLACK ANTI CANT DEVICE

[Optics & Mounting](#) > [Optic Accessories](#) > [Scope Anti-Cant Devices](#)

Stay On Target, Shot After Shot

Gives an instant check to make sure the gun is perfectly level for every shot, so every shot goes where it's aimed. If you sighted in carefully at 100 yards with the crosshairs level, then canted the gun just six degrees you'd move the next shot over 1/2". Not much, but enough to completely miss a small target, or wound a larger one. The problem gets worse at longer ranges. Clamp the ACD on the scope tube where it's visible to the non-sighting eye.



Attributes

- Name: [MOUNTING SOLUTIONS PLUS 1" BLACK ANTI CANT DEVICE](#)
- Manufacturer: [MOUNTING SOLUTIONS PLUS](#)
- Product no.: 556200100
- Mfr. No.: LOPA10010
- Finish: Matte Black
- Tube Size: 1"
- Delivery weight: 0.023kg
- Shipping height: 13mm
- Shipping width: 109mm
- Shipping length: 155mm

Item details

Made in USA

Table of Contents

- Startpage
- ANTI CANT DEVICE MOUNTING SOLUTIONS PLUS 1" BLACK ANTI CANT DEVICE Safety Instruction Guide
- About Us

ANTI CANT DEVICE MOUNTING SOLUTIONS PLUS

1" BLACK ANTI CANT DEVICE Safety Instruction Guide

Introduction

Thank you for choosing the ANTI CANT DEVICE MOUNTING SOLUTIONS PLUS 1" BLACK ANTI CANT DEVICE. This device is designed to ensure your firearm is level for accurate shooting. Please read this safety instruction guide carefully to understand how to use the product safely and effectively.

General Safety Guidelines

- Ensure that the product is used only for its intended purpose.
- Always handle firearms with care and follow all safety protocols.
- Keep the device out of reach of children and unauthorized users.
- Regularly check the device for any signs of wear or damage before use.
- Report any unsafe products or accidents to the appropriate authorities.
- Stay informed about product recalls by checking the EU's Safety Gate platform.

Specific Safety Precautions for Use

- Before using the device, ensure that your firearm is unloaded.
- Always use the device in a safe environment, away from people and animals.
- Do not modify the device in any way, as this may compromise its safety.
- If the device becomes loose during use, stop using it immediately and secure it properly.
- Be aware of your surroundings and ensure that your line of sight is clear before taking a shot.

Instructions for Installation and Usage

1. Installation:

- Clamp the ANTI CANT DEVICE onto the scope tube where it is visible to your nonsighting eye.
- Ensure that the device is securely attached and does not obstruct your view.
- Check that the device is level before proceeding to use it.

2. Usage:

- Align the crosshairs of your scope with your target while ensuring the device indicates a level position.
- If the device shows that the firearm is canted, adjust your stance or the firearm until the device indicates it is level.
- Take your shot only when you are confident that the firearm is level and aimed correctly.

Disposal Instructions

- Dispose of the device in accordance with local regulations regarding electronic waste and metal disposal.
- If the device is damaged or no longer functional, do not attempt to repair it; instead, dispose of it responsibly.

Contact Information for Further Support

For any questions or concerns regarding the ANTI CANT DEVICE, please refer to the manufacturer's website or customer service for support. Ensure that you have your purchase information handy for reference.

By adhering to these safety guidelines and instructions, you can enhance your shooting accuracy while ensuring your safety and the safety of those around you. Thank you for choosing our product, and happy shooting!

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk