

UNCLE MIKE'S QUICK DETACH 100 SLING SWIVEL - 1" QD-100 LOOPS ONLY, 2-PAK

[Shooting Accessories](#) > [Slings & Sling Swivels](#) > [Flush Mount Sling Swivels](#)

Universal Design Fits Virtually Every Bolt Action Rifle Made

Quickly attaches or detaches with recessed push button. Provides secure sling attachment that can't come loose. Mounting system will fit nearly every centerfire or rimfire bolt action made, plus many other action types. When detached, leaves a non-snag, flush base. Use Epoxy to hold base in stock, no screw required.



Attributes

- Name: [1" QD-100 LOOPS ONLY, 2-PAK](#)
- Manufacturer: [UNCLE MIKES](#)
- Product no.: 593000037
- Mfr. No.:
- Make: Michaels of Oregon
- Material: Steel
- Style: Flush Mount Swivel
- Delivery weight: 0.032kg
- Shipping width: 83mm
- Shipping length: 146mm

Table of Contents

- Startpage
- UNCLE MIKE'S QUICK DETACH 100 SLING SWIVEL 1" QD100 LOOPS ONLY, 2PAK Safety Instructions
- About Us

UNCLE MIKE'S QUICK DETACH 100 SLING SWIVEL 1" QD100 LOOPS ONLY, 2PAK Safety Instructions

Introduction

Thank you for choosing the UNCLE MIKE'S QUICK DETACH 100 SLING SWIVEL. This product is designed for secure and convenient attachment of slings to your firearm. To ensure your safety and the safety of others, please read this guide carefully before use.

General Safety Guidelines

- Always handle firearms and accessories with care.
- Ensure that the sling swivel is compatible with your firearm before installation.
- Regularly inspect the sling swivel for signs of wear or damage.
- Do not exceed the manufacturer's weight limit when using the sling swivel.
- Keep this product out of reach of children and unauthorized users.
- Report any unsafe products or accidents to the relevant authorities.

Specific Safety Precautions for Use

- Ensure that the recessed push button is functioning correctly before use.
- Do not force the push button; it should operate smoothly.
- Avoid using the sling swivel if it appears damaged or compromised.
- When detaching the sling, ensure that the area is clear of obstructions to prevent injury.
- Use the sling swivel only for its intended purpose; do not modify the product.

Instructions for Installation and Usage

1. Preparation:

- Gather the necessary tools, including epoxy for securing the base.
- Ensure you have a clean and dry workspace.

2. Installation:

- Identify the mounting location on your firearm's forend.
- Ensure the forend wood is at least 5/8" (16mm) thick for proper mounting.
- Apply epoxy to the base of the sling swivel.
- Press the base firmly into place on the forend and allow the epoxy to cure as per the manufacturer's instructions.
- Ensure that the base is flush and secure before attaching the sling.

3. Usage:

- To attach the sling, press the recessed push button and slide the sling into place.
- To detach the sling, press the push button again and remove the sling.
- Always check that the sling is securely attached before use.

Disposal Instructions

- Dispose of the product in accordance with local regulations.
- Do not dispose of the product in regular household waste.
- If the product is damaged or no longer usable, consider recycling options where available.

Contact Information for Further Support

For any inquiries related to safety or product support, please contact your local retailer or the manufacturer directly. Ensure you have your product details at hand for efficient assistance.

Thank you for prioritizing safety while using the UNCLE MIKE'S QUICK DETACH 100 SLING SWIVEL. Enjoy your experience and stay safe!

About Us

Brownells Austria

Brownells - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

www.brownells.at