

FLIP OPEN EYEPIECE LENS COVERS - BUTLER CREEK EYEPIECE LENS COVER #7 1.457" (37.0MM)

[Optics & Mounting](#) > [Optic Accessories](#) > [Scope Lens Covers](#)

Keeps Harmful Debris From Scratching Or Abusing Lenses

Weatherproof, dust-proof, moisture-proof scope covers protect your scope's lenses from being damaged during tactical and hunting situations. Cover flips open easily with finger pressure to spring up, and out of the way. Eye and Objective covers sold separately. To determine the correct scope cover, measure the diameter of your scope eyepiece or objective and use the chart.



Attributes

- Name: [BUTLER CREEK EYEPIECE LENS COVER #7 1.457" \(37.0MM\)](#)
- Manufacturer: [BUTLER CREEK](#)
- Product no.: 593000156
- Mfr. No.: MO20070
- Colour: Black
- End Fit: Ocular
- Model Number: 1.457" (37.0MM)
- Optic Model: -
- Size: 1.457
- Delivery weight: 0.023kg
- Shipping height: 41mm
- Shipping width: 71mm
- Shipping length: 122mm
- UPC: 051525200703

Table of Contents

- Startpage
- FLIP OPEN EYEPIECE LENS COVERS SAFETY INSTRUCTIONS
- About Us

FLIP OPEN EYEPIECE LENS COVERS SAFETY INSTRUCTIONS

Introduction

Thank you for choosing the Butler Creek Eyepiece Lens Cover #7. This product is designed to protect your scope's lenses from damage during tactical and hunting situations. To ensure safe and effective use, please read this safety instruction guide carefully.

General Safety Guidelines

- Always inspect the lens cover before use to ensure it is free from damage.
- Ensure that the lens cover is compatible with your scope by measuring the eyepiece diameter.
- Use the lens cover only for its intended purpose.
- Keep the lens cover out of reach of children to prevent accidental injury or misuse.
- Report any unsafe conditions or incidents to the appropriate authorities.

Specific Safety Precautions for Use

- Do not attempt to modify the lens cover in any way.
- Avoid exposing the lens cover to extreme temperatures, which may affect its performance.
- Ensure that the lens cover is securely closed when not in use to protect against dust and moisture.
- Be cautious when flipping the cover open; ensure that your fingers are clear of the mechanism to avoid injury.
- If the lens cover becomes damaged, discontinue use immediately and replace it.

Instructions for Installation and Usage

1. Measuring Your Scope:

- Measure the diameter of your scope eyepiece to ensure you select the correct lens cover size. The Butler Creek Eyepiece Lens Cover #7 is designed for eyepieces measuring 1.457 inches (37.0 mm).

2. Installation:

- Align the lens cover over the eyepiece of your scope.
- Press the lens cover down firmly until it fits snugly in place.
- Ensure that the cover is seated properly to prevent any dust or moisture from entering.

3. Usage:

- To flip the cover open, apply gentle finger pressure to the designated area.
- The cover will spring up and out of the way, allowing for quick access to your scope.
- After use, close the lens cover securely to protect the lens.

4. Maintenance:

- Regularly clean the lens cover with a soft, dry cloth to remove dust and debris.
- Store the lens cover in a cool, dry place when not in use.

Disposal Instructions

- Dispose of the lens cover in accordance with local regulations.
- Do not dispose of the lens cover in household waste if it is damaged or poses a safety risk.
- Consider recycling the product if possible.

Contact Information for Further Support

For any inquiries regarding the Butler Creek Eyepiece Lens Cover #7, please consult the manufacturer or your retailer for assistance. Always ensure you have the product details ready when seeking support.

Thank you for your attention to these safety instructions. Enjoy using your Butler Creek Eyepiece Lens Cover safely and effectively.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk