

1911 ADJUSTABLE WHITE DOT REAR SIGHTS - NOVAK REAR SIGHTS, WD FITS COLT

[Handgun Parts](#) > [Sights](#) > [Rear Sights](#)

CNC-machined, steel, rear sight with Novak's famous, low-profile design and the added versatility of elevation and windage adjustments. Set screw allows drift adjustment for windage; elevation screw positively stops and audibly clicks for easy fine-tuning. Smooth, contoured edges have less chance of catching or snagging. Available in for Colt and SW1911 pistols.



Attributes

- Name: [NOVAK REAR SIGHTS, WD FITS COLT](#)
- Manufacturer: [NOVAK](#)
- Product no.: 625000010
- Mfr. No.: ALM02
- Model: Commander, Government, Officers
- Sight Color: White
- Style: 2-Dot, Low-Profile
- Weapon type: 1911
- Delivery weight: 0.045kg
- Shipping height: 1mm
- Shipping width: 83mm
- Shipping length: 146mm
- UPC: 765595551503

Item details

Made in USA

Table of Contents

- Startpage
- Safety Instruction Guide for 1911 Adjustable White Dot Rear Sights
- About Us

Safety Instruction Guide for 1911 Adjustable White Dot Rear Sights

Introduction

Thank you for choosing the 1911 Adjustable White Dot Rear Sights by Novak. This guide provides important safety instructions and guidelines to ensure the safe use and installation of your new rear sights. Please read this manual carefully before using the product.

General Safety Guidelines

- Ensure that the firearm is unloaded before installing or adjusting the rear sights.
- Always handle firearms with care and respect, following all local laws and regulations.
- Keep the rear sights out of reach of children and unauthorized users.
- Regularly inspect the rear sights for any signs of wear or damage.
- Report any unsafe product conditions to the appropriate authorities.
- Stay informed about product recalls through the EU's Safety Gate platform.

Specific Safety Precautions for Use

- Only use the rear sights on compatible models: Colt and SW1911 pistols.
- Avoid using excessive force when making adjustments to prevent damage to the sight or firearm.
- Do not modify the rear sights in any way that could compromise their safety or functionality.
- Ensure that the sight is securely installed before using the firearm.
- Be aware of your surroundings and ensure a safe shooting environment.

Instructions for Installation and Usage

1. Installation of Rear Sights:

- Ensure the firearm is unloaded.
- Remove the existing rear sight if applicable.
- Align the Novak rear sight with the mounting dovetail on the firearm.
- Use the set screw to secure the sight in place.
- Adjust for windage using the drift adjustment feature.
- Adjust for elevation using the elevation screw, ensuring it clicks into place for proper adjustment.

2. Usage of Rear Sights:

- Familiarize yourself with the sight picture before shooting.
- Regularly check the alignment and tightness of the rear sight during use.
- Practice safe shooting habits and always point the firearm in a safe direction.

Disposal Instructions

- Dispose of any packaging materials in accordance with local waste disposal regulations.
- If the rear sights become damaged or are no longer usable, dispose of them in a way that prevents unauthorized use, such as by destroying them.

Contact Information for Further Support

For any questions or concerns regarding the installation or usage of your 1911 Adjustable White Dot Rear

Sights, please contact the manufacturer or your local retailer for assistance.

Thank you for prioritizing safety while using your new rear sights. Enjoy your shooting experience responsibly!

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk