

1911 45ACP MAGAZINES - MEC-GAR 1911 AUTO .45 ACP BRIGHT NICKEL 7 RND.

[Magazines](#) > [Handgun Magazines](#) > [Magazines](#)

Expert Craftsmanship; Reliable Function

Made from certified, carbon steel; TIG welded (not removable) and finished without seams, then heat treated for durability with steel followers. Also available with a rustproof, nickel finish. These are the same magazines that are supplied by many European handgun makers as original equipment.



Attributes

- Name: [MEC-GAR 1911 AUTO .45 ACP BRIGHT NICKEL 7 RND.](#)
- Manufacturer: [MEC-GAR](#)
- Product no.: 625201457
- Mfr. No.: MGCG4507N
- Capacity: 7-Round
- Cartridge: 45 Auto (ACP)
- Finish: Nickel
- Make: 1911
- Material: Steel
- Model: Commander, Government
- Delivery weight: 0.068kg
- UPC: 765595103603

Item details

US export classification: 0A501.x

Table of Contents

- Startpage
- Safety Instruction Guide for MECGAR 1911 .45 ACP Magazines
- About Us

Safety Instruction Guide for MECGAR 1911 .45 ACP Magazines

Introduction

Thank you for choosing the MECGAR 1911 .45 ACP Magazines. This guide provides essential safety instructions to ensure the safe use, installation, and disposal of your magazines. Please read this document carefully before using the product to ensure compliance with safety guidelines and regulations.

General Safety Guidelines

- Ensure that the magazine is compatible with your firearm model (Government or Commander).
- Always handle magazines and firearms with care, treating them as if they are loaded.
- Keep the magazines out of reach of children and unauthorized users.
- Regularly inspect the magazine for signs of wear or damage before use.
- Store magazines in a cool, dry place away from direct sunlight and moisture.
- Follow all local laws and regulations regarding the use and storage of firearms and ammunition.

Specific Safety Precautions for Use

- Always ensure the firearm is unloaded before inserting or removing the magazine.
- Do not attempt to modify or disassemble the magazine.
- Use only .45 ACP ammunition that is in good condition and free from defects.
- Avoid overloading the magazine beyond its 7round capacity.
- If the magazine fails to feed or eject properly, cease use immediately and inspect for obstructions or damage.
- In case of a malfunction, follow the safety protocols of your firearm manufacturer.

Instructions for Installation and Usage

1. Installation:

- Ensure the firearm is pointed in a safe direction and is unloaded.
- Align the magazine with the magazine well of the firearm.
- Firmly push the magazine into the well until it clicks into place.

2. Usage:

- Load the magazine by inserting .45 ACP rounds into the magazine, ensuring they are positioned correctly.
- Always check that the magazine is securely seated in the firearm before attempting to fire.
- After firing, remove the magazine by pressing the magazine release button and pulling the magazine out of the firearm.

Disposal Instructions

- Dispose of damaged or worn magazines in accordance with local regulations.
- If the magazine is no longer usable, consider contacting a local firearms dealer for proper disposal methods.
- Avoid discarding magazines in regular trash to prevent unauthorized access.

Contact Information for Further Support

For any inquiries regarding safety, usage, or concerns about the MECGAR 1911 .45 ACP Magazines, please contact your local dealer or the manufacturer directly.

Conclusion

By following these safety guidelines and instructions, you can ensure a safe and enjoyable experience with your MECGAR 1911 .45 ACP Magazines. Always prioritize safety and compliance with local laws for responsible firearm ownership.

About Us

Brownells Europe

Brownells Europe - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

P.O.Box 4300
Warwick
CV34 9BR

www.brownells.eu