

LITEWAVE REAR SIGHTS FOR GLOCK - HIVIZ GLOCK® LITEWAVE REAR SIGHT 6.1MM

[Handgun Parts](#) > [Sights](#) > [Sight Sets](#)

The new LITEWAVE sight design from HIVIZ features an innovative, diagonal-wave design that increases durability to the protective exoskeleton and allows for more exposed surface area for the LITEPIPE to gather light from all angles, for the brightest sight available. GLLW11 is 6.1mm high, and fits models 42 and 43. GLLW15 LITEWAVE Rear Sight is 6.5mm high, and fits 9mm, .40 S&W, and .357 Sig models. All rear sights include red, green, and black LitePipes.



Attributes

- Name: [HIVIZ GLOCK® LITEWAVE REAR SIGHT 6.1MM](#)
- Manufacturer: [HIVIZ](#)
- Product no.: 638000201
- Mfr. No.: GLLW11
- Model: 42,43
- Sight Color: Black,Red/Green
- Style: 3-Dot,Fiber Optic
- Weapon type: Glock
- Delivery weight: 0.023kg
- Shipping height: 6mm
- Shipping width: 102mm
- Shipping length: 165mm
- UPC: 613485589313

Item details

Made in USA

Table of Contents

- [Startpage](#)
- [LITEWAVE Rear Sights for Glock Safety Instruction Guide](#)
- [About Us](#)

LITEWAVE Rear Sights for Glock Safety Instruction Guide

Introduction

Thank you for choosing the LITEWAVE Rear Sights for your Glock. This guide provides important safety instructions and information to ensure the safe use and installation of your new sights. Please read this guide carefully before use.

General Safety Guidelines

- Ensure that the LITEWAVE Rear Sights are installed correctly and securely to avoid any accidents or malfunctions.
- Always treat your firearm with respect and follow all safety protocols associated with handling firearms.
- Keep the sights and the firearm out of reach of children and vulnerable individuals.
- Regularly inspect the sights for any signs of wear or damage before each use.
- If you notice any defects or issues, discontinue use immediately and seek assistance.

Specific Safety Precautions for Use

- Use only with Glock models 42 and 43 (GLLW11) or 9mm, .40 S&W, and .357 Sig models (GLLW15).
- Ensure that the firearm is unloaded before installing or adjusting the sights.
- Avoid using excessive force when installing the sights to prevent damage.
- Do not attempt to modify the sights in any way, as this may compromise their safety and effectiveness.
- Be aware of your surroundings and ensure a safe shooting environment at all times.

Instructions for Installation and Usage

1. Installation Instructions:

- Ensure the firearm is unloaded.
- Remove the existing rear sight using a sight pusher or appropriate tool.
- Align the LITEWAVE Rear Sight with the dovetail slot on the slide.
- Gently press the sight into place, ensuring it is seated correctly.
- Secure the sight using the appropriate screws, if applicable.
- Check that the sight is aligned properly and does not move.

2. Usage Instructions:

- Familiarize yourself with the sight picture before using the firearm.
- Adjust your shooting stance and grip to ensure optimal visibility of the sights.
- Practice regularly to become accustomed to the new sight system.

Disposal Instructions

- Dispose of the LITEWAVE Rear Sights responsibly at a local waste disposal facility or recycling center.
- Follow local regulations for the disposal of firearms accessories.

Contact Information for Further Support

For any questions or concerns regarding the LITEWAVE Rear Sights, please refer to the manufacturer's contact information provided in the product packaging or visit the manufacturer's website for support.

Conclusion

By following these safety instructions and guidelines, you can ensure a safe and enjoyable experience with your LITEWAVE Rear Sights for Glock. Always prioritize safety when handling firearms and accessories. Thank you for your purchase!

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk