


RUGER® HAMMER & TRIGGER SHIMS - POWER CUSTOM RUGER® SA HAMMER SHIMS

[Handgun Parts](#) > [Trigger Group Parts](#) > [Trigger Parts](#) > [Trigger Hardware](#)

Eliminates excessive side-to-side movement of hammer and trigger for wobble-free cycling. Available in 10-paks.



Attributes

- Name: [POWER CUSTOM RUGER® SA HAMMER SHIMS](#)
- Manufacturer: [POWER CUSTOM](#)
- Product no.: 713000063
- Mfr. No.: NONE
- Model: Blackhawk
- Weapon type: Ruger
- Delivery weight: 0.045kg
- Shipping height: 13mm
- Shipping width: 117mm
- Shipping length: 112mm

Item details

Made in USA

Table of Contents

- Startpage
- RUGER® HAMMER & TRIGGER SHIMS SAFETY INSTRUCTION GUIDE
- About Us

RUGER® HAMMER & TRIGGER SHIMS SAFETY INSTRUCTION GUIDE

Introduction

Thank you for choosing the RUGER® HAMMER & TRIGGER SHIMS by POWER CUSTOM. This product is designed to eliminate excessive sidetoside movement of the hammer and trigger, ensuring a wobblefree cycling experience. Please read this safety instruction guide carefully to ensure safe and effective use of the product.

General Safety Guidelines

- Ensure that the product is used only for its intended purpose.
- Always handle firearms and related accessories with care and respect.
- Keep the product out of reach of children and unauthorized users.
- Regularly inspect the shims for wear and tear before each use.
- Report any unsafe products or incidents to the appropriate authorities.
- Stay informed about recall updates through the EU's Safety Gate platform.

Specific Safety Precautions for Use

- Only use the shims with Ruger® SA revolvers, excluding the Bearcat model.
- Verify that the thickness of the shims (.004" to .005") is appropriate for your firearm.
- Ensure that the shims are installed correctly to prevent any malfunction.
- Do not exceed the recommended number of shims for your firearm to avoid operational issues.
- Always wear safety glasses when working on firearms to protect your eyes from debris.

Instructions for Installation and Usage

1. Preparation:

- Make sure your firearm is unloaded and pointed in a safe direction.
- Gather necessary tools, including a screwdriver and cleaning cloth.

2. Installation:

- Remove the hammer and trigger from the firearm according to the manufacturer's instructions.
- Clean the surfaces where the shims will be installed to ensure a proper fit.
- Select the appropriate shim thickness based on your firearm's requirements.
- Place the shims in the designated areas to minimize movement of the hammer and trigger.
- Reassemble the hammer and trigger, ensuring all components are securely in place.

3. Usage:

- After installation, test the firearm in a safe environment to ensure proper function.
- Monitor the performance of the firearm and check for any unusual sounds or movements during use.
- If any issues arise, stop using the firearm immediately and consult a qualified gunsmith.

Disposal Instructions

- Dispose of any damaged or worn shims responsibly.
- Follow local regulations regarding the disposal of metal products.
- Recycle materials whenever possible to minimize environmental impact.

Contact Information for Further Support

For any questions or concerns regarding the RUGER® HAMMER & TRIGGER SHIMS, please consult your local dealer or refer to the manufacturer's website. It is essential to have access to a knowledgeable source for guidance on product safety and usage.

By adhering to these safety instructions, you can ensure a safe and effective experience with your RUGER® HAMMER & TRIGGER SHIMS. Thank you for prioritizing safety in your firearm handling practices.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk