

RUGER® LARGE FRAME SA LOADING GATE SPRING - POWER CUSTOM LOADING GATE SPRING

[Handgun Parts](#) > [Action Parts](#) > [Gate Parts](#) > [Gate Springs](#)

Heat-treated, loading gate spring has more metal in areas needing additional strength and less metal in thinner areas for a lighter, softer spring. Drops in all large frame Ruger® SA revolvers.



Attributes

- Name: [POWER CUSTOM LOADING GATE SPRING](#)
- Manufacturer: [POWER CUSTOM](#)
- Product no.: 713000065
- Mfr. No.: NONE
- Model: Vaquero
- Weapon type: Ruger
- Delivery weight: 0.045kg
- Shipping height: 8mm
- Shipping width: 94mm
- Shipping length: 114mm

Item details

Made in USA

Table of Contents

- Startpage
- RUGER® Large Frame SA Loading Gate Spring Safety Instructions
- About Us

RUGER® Large Frame SA Loading Gate Spring Safety Instructions

Introduction

Thank you for choosing the RUGER® Large Frame SA Loading Gate Spring by POWER CUSTOM. This product is designed to enhance the performance of your Ruger® SA revolver. To ensure your safety and the proper functioning of the product, please read this safety instruction guide carefully before use.

General Safety Guidelines

- Always handle firearms and related components with care, following all safety protocols.
- Ensure the product is compatible with your specific Ruger® SA revolver model.
- Inspect the loading gate spring for any signs of damage before installation.
- Store the product in a safe location, out of reach of children and unauthorized users.
- Report any unsafe products or incidents to the relevant authorities immediately.
- Stay informed about product recalls or safety updates via the EU Safety Gate platform.

Specific Safety Precautions for Use

- Do not use the loading gate spring if it shows signs of wear or damage.
- Ensure that the firearm is unloaded before attempting to install or replace the loading gate spring.
- Only use the product in accordance with the manufacturer's specifications.
- Be cautious of the spring tension during installation to avoid injury.
- Keep hands clear of the loading gate area while the firearm is being operated.

Instructions for Installation and Usage

1. Preparation

- Ensure the firearm is unloaded and pointed in a safe direction.
- Gather necessary tools for installation (e.g., screwdriver, pliers).

2. Removal of Old Spring

- Carefully remove the existing loading gate spring from the firearm.
- Inspect the area for any debris or damage.

3. Installation of New Spring

- Take the new loading gate spring and align it with the loading gate mechanism.
- Gently insert the spring into its designated slot, ensuring it is seated properly.
- Apply appropriate pressure to secure the spring in place without forcing it.

4. Final Check

- After installation, check the loading gate for proper operation.
- Ensure the spring functions smoothly without obstruction.

5. Usage

- Operate the firearm according to standard safety practices.
- Regularly inspect the loading gate spring for signs of wear or malfunction.

Disposal Instructions

- Dispose of any old or damaged loading gate springs in accordance with local waste management regulations.
- Do not dispose of the product in regular household waste. Check for recycling options or designated disposal sites for metal components.

Contact Information for Further Support

For any inquiries or further assistance regarding the RUGER® Large Frame SA Loading Gate Spring, please refer to the manufacturer's contact information provided on the packaging or product literature.

By following these guidelines and instructions, you ensure a safe and effective experience with your RUGER® Large Frame SA Loading Gate Spring. Thank you for your attention to safety.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk