

RUGER® 10/22® ALUMINUM TRIGGER - 10/22® TRIGGER, BLACK

[Rifle Parts](#) > [Triggers Parts](#) > [Triggers](#)

Machined aluminum trigger has a wide, smooth face and sits lower than the factory trigger to give you better control with less pressure needed for release. Includes over-travel adjustment screw (hex wrench included) and a pre-drilled hole that allows easy access to adjust the sear pre-travel.



Attributes

- Name: [10/22® TRIGGER, BLACK](#)
- Manufacturer: [POWER CUSTOM](#)
- Product no.: 713000091
- Mfr. No.: NONE
- Make: Ruger
- Model: 10/22
- Style: Adjustable
- Delivery weight: 0.018kg
- Shipping height: 10mm
- Shipping width: 102mm
- Shipping length: 127mm

Item details

Made in USA

US export classification: 0A501.c

Table of Contents

- Startpage
- RUGER® 10/22® Aluminum Trigger Safety Instruction Guide
- About Us

RUGER® 10/22® Aluminum Trigger Safety Instruction Guide

Introduction

Thank you for purchasing the RUGER® 10/22® Aluminum Trigger. This guide provides essential safety instructions and guidelines to ensure safe and effective use of your new trigger. Please read this document carefully before installation and use.

General Safety Guidelines

- Ensure that all safety precautions are followed during installation and usage.
- Always treat your firearm and its components with respect and caution.
- Keep the product out of reach of children and unauthorized users.
- Regularly inspect the trigger and firearm for any signs of wear or damage.
- If you are unsure about any aspect of installation or use, seek assistance from a qualified gunsmith.

Specific Safety Precautions for Use

- Always ensure that the firearm is unloaded before handling or installing the trigger.
- Use the trigger only with the RUGER® 10/22® model to avoid compatibility issues.
- Do not modify the trigger or firearm in any way that could compromise safety.
- Be aware of your surroundings and ensure a safe shooting environment.
- Wear appropriate eye and ear protection when using the firearm.

Instructions for Installation and Usage

1. Preparation:

- Gather all necessary tools, including the provided hex wrench.
- Ensure that the firearm is completely unloaded and pointed in a safe direction.

2. Installation:

- Remove the factory trigger from the RUGER® 10/22® following the manufacturer's instructions.
- Install the RUGER® 10/22® Aluminum Trigger by aligning it with the trigger assembly.
- Use the hex wrench to tighten the adjustment screw securely.
- Adjust the sear pretravel using the predrilled hole for easy access.

3. Final Checks:

- After installation, conduct a function test to ensure proper operation.
- Verify that the trigger operates smoothly without any obstruction.

4. Usage:

- Always follow standard firearm safety rules while using your firearm.
- Regularly check the trigger for any signs of wear or malfunction.

Disposal Instructions

- Dispose of the product in accordance with local regulations.
- Do not dispose of the product in household waste. Check with local authorities for proper disposal

methods.

Contact Information for Further Support

For any inquiries or concerns regarding the RUGER® 10/22® Aluminum Trigger, please contact the manufacturer or a qualified firearms expert for assistance.

It is essential to stay informed about product recalls and safety alerts. Regularly check the EU's Safety Gate platform for updates on unsafe products and recalls.

Thank you for prioritizing safety and responsible use of your RUGER® 10/22® Aluminum Trigger.

About Us

Brownells Austria

Brownells - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

www.brownells.at