

# SLIDE CATCH LEVER FOR SIG SAUER P239 - P239 40/357 SLIDE CATCH LEVER, BLUE

[Handgun Parts](#) > [Frame Parts](#) > [Slide Catch Parts](#) > [Slide Catches](#)

Factory replacement slide catch lever for Sig Sauer P239.



## Attributes

- Name: [P239 40/357 SLIDE CATCH LEVER, BLUE](#)
- Manufacturer: [SIG SAUER, INC.](#)
- Product no.: 732000333
- Mfr. No.: 1200781-R
- Caliber: 38/357 Caliber (.357-.359)
- Finish: Blued
- Make: Sig Sauer
- Model: P239
- Delivery weight: 0.005kg
- Shipping height: 1mm
- Shipping width: 83mm
- Shipping length: 146mm
- UPC: 798681218981

## Item details

Made in USA

US export classification: 0A501.x

# Table of Contents

- Startpage
- SLIDE CATCH LEVER FOR SIG SAUER P239 Safety Instruction Guide
- About Us

# SLIDE CATCH LEVER FOR SIG SAUER P239 Safety Instruction Guide

## Introduction

Thank you for choosing the SLIDE CATCH LEVER for your Sig Sauer P239. This guide provides essential safety instructions and guidelines to ensure safe and effective use of the product. Please read this document carefully before installation and usage.

## General Safety Guidelines

- Ensure that the product is compatible with your specific firearm model.
- Always handle firearms with care and follow standard safety practices.
- Keep the product out of reach of children and vulnerable individuals.
- Regularly inspect the slide catch lever for signs of wear or damage.
- Do not use the product if it appears to be defective or damaged.
- Report any unsafe products or accidents to the appropriate authorities.
- Check for recall updates on the EU's Safety Gate platform.

## Specific Safety Precautions for Use

- Always ensure the firearm is unloaded before installing or replacing the slide catch lever.
- Wear safety glasses when working with firearms to protect your eyes from debris.
- Avoid exposing the slide catch lever to extreme temperatures or harsh chemicals.
- Do not attempt to modify the slide catch lever or any part of the firearm.
- Follow the manufacturer's guidelines for maintenance and care of the firearm.

## Instructions for Installation and Usage

### 1. Preparation

- Ensure your Sig Sauer P239 is completely unloaded.
- Gather necessary tools for installation, including a screwdriver and any specific tools recommended by the manufacturer.

### 2. Removing the Old Slide Catch Lever

- Remove the slide from the firearm according to the manufacturer's instructions.
- Locate the existing slide catch lever.
- Carefully unscrew and remove the old slide catch lever.

### 3. Installing the New Slide Catch Lever

- Align the new slide catch lever with the designated area on the firearm.
- Securely screw in the new slide catch lever, ensuring it is firmly in place.
- Reattach the slide to the firearm, ensuring all components are correctly aligned.

### 4. Final Checks

- Perform a function check to ensure the slide catch lever operates correctly.
- Confirm that the firearm is in a safe condition before handling further.

## Disposal Instructions

- Dispose of any old or damaged parts in accordance with local regulations.
- Do not dispose of the product in household waste. Instead, follow proper electronic waste disposal procedures if applicable.

## Contact Information for Further Support

For any questions or concerns regarding the SLIDE CATCH LEVER, please refer to the manufacturer's official website or contact their customer support for assistance. Always ensure that you have the latest information regarding product safety and usage.

By following these guidelines, you can help ensure your safety and the proper functioning of your firearm. Remember that safety is paramount when handling firearms and their components.

# About Us

## **Brownells Česká republika**

**Brownells - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories**

[www.brownells.cz](http://www.brownells.cz)