

SIG SAUER 320 FINE BLANK SAFETY LOCK

[Handgun Parts](#) > [Safety Parts](#) > [Safeties](#)

Sig Sauer factory Fine Blank Safety Lock for the P320.



Attributes

- Name: [SIG SAUER 320 FINE BLANK SAFETY LOCK](#)
- Manufacturer: [SIG SAUER, INC.](#)
- Product no.: 732000599
- Mfr. No.: 1301029-R
- Finish: Black
- Hand: Ambidextrous
- Make: Sig Sauer
- Model: P320
- Style: Factory Replacement
- Delivery weight: 0.068kg
- Shipping height: 5mm
- Shipping width: 102mm
- Shipping length: 191mm
- UPC: 798681540075

Item details

Made in USA

US export classification: 0A501.x

Table of Contents

- Startpage
- SIG SAUER 320 Fine Blank Safety Lock User Manual
- About Us

SIG SAUER 320 Fine Blank Safety Lock User Manual

Introduction

Thank you for choosing the SIG SAUER 320 Fine Blank Safety Lock. This product is designed to enhance the safety of your P320 firearm. Please read this manual carefully to ensure safe and effective use of the safety lock.

General Safety Guidelines

- Ensure that the safety lock is used only with the SIG SAUER P320 model.
- Always handle firearms with care and follow basic firearm safety rules.
- Store the safety lock in a secure location, away from children and unauthorized users.
- Regularly inspect the safety lock for any signs of wear or damage before each use.
- Report any unsafe conditions or incidents related to the product to the appropriate authorities.

Specific Safety Precautions for Use

- This product is intended for adult use only. Keep it out of reach of children.
- Do not attempt to modify or alter the safety lock in any way.
- Always ensure that the firearm is unloaded before installing or removing the safety lock.
- Use the safety lock only as directed in this manual.
- If you experience any difficulties during installation or use, cease use immediately and consult a professional.

Instructions for Installation and Usage

1. Installation:

- Ensure that the firearm is completely unloaded.
- Locate the safety lock mechanism on the P320.
- Insert the safety lock into the designated slot until it clicks into place.
- Verify that the safety lock is securely attached by gently tugging on it.

2. Usage:

- The safety lock is designed to prevent unauthorized use of the firearm.
- Always check that the safety lock is engaged before storing the firearm.
- To remove the safety lock, ensure the firearm is unloaded, then press the release button while gently pulling the lock out of the slot.

3. Maintenance:

- Regularly clean the safety lock with a dry cloth to remove any dirt or debris.
- Do not use any harsh chemicals or solvents that may damage the safety lock.

Disposal Instructions

- Dispose of the safety lock in accordance with local regulations.
- Do not dispose of the safety lock in regular household waste.
- If the safety lock is damaged or no longer functional, contact your local waste management authority for proper disposal methods.

Contact Information for Further Support

For questions or concerns regarding the SIG SAUER 320 Fine Blank Safety Lock, please refer to the manufacturer's contact information provided with the product packaging or visit the official SIG SAUER website for assistance.

By following these guidelines and instructions, you can ensure the safe and effective use of your SIG SAUER 320 Fine Blank Safety Lock. Thank you for prioritizing safety.

About Us

Brownells Česká republika

Brownells - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

www.brownells.cz