

# SIG SAUER P365 NON-TEXTURED SLIDE CAP

[Handgun Parts](#) > [Slide Parts](#) > [Slide Hardware](#) > [Slide Covers](#)

Replacement non-textured slide cap for the Sig Sauer P365.



## Attributes

- Name: [SIG SAUER P365 NON-TEXTURED SLIDE CAP](#)
- Manufacturer: [SIG SAUER, INC.](#)
- Product no.: 732000660
- Mfr. No.: KIT-365-SLIDE-CAP
- Make: Sig Sauer
- Model: P365
- Delivery weight: 0.009kg
- Shipping height: 5mm
- Shipping width: 102mm
- Shipping length: 191mm
- UPC: 798681594047

## Item details

US export classification: 0A501.x

# Table of Contents

- Startpage
- SIG SAUER P365 NonTextured Slide Cap Safety Instruction Guide
- About Us

# SIG SAUER P365 NonTextured Slide Cap Safety Instruction Guide

## Introduction

Thank you for choosing the SIG SAUER P365 NonTextured Slide Cap. This guide provides important safety information and instructions to ensure the safe use and installation of this product. It is essential to follow these guidelines to prevent accidents and ensure the product's longevity.

## General Safety Guidelines

- Ensure that the slide cap is compatible with your SIG SAUER P365 model before use.
- Always inspect the slide cap for any signs of damage or wear before installation.
- Keep the slide cap out of reach of children and vulnerable individuals.
- Do not attempt to modify or alter the slide cap in any way.
- If you notice any defects or issues during installation or use, discontinue use immediately and seek assistance.

## Specific Safety Precautions for Use

- **Compatibility:** Verify that this slide cap is specifically designed for the SIG SAUER P365. Using it with incompatible models may lead to malfunction or injury.
- **Installation:** Follow the installation instructions carefully to avoid improper fitting, which could cause safety hazards.
- **Handling:** Handle the slide cap with care. Avoid dropping or subjecting it to extreme conditions, as this may compromise its integrity.
- **Cleaning:** Use a soft, dry cloth for cleaning. Do not use harsh chemicals or abrasive materials, as they may damage the slide cap.
- **Storage:** Store the slide cap in a cool, dry place when not in use. Avoid exposure to moisture and extreme temperatures.

## Instructions for Installation and Usage

### 1. Preparation:

- Ensure that your firearm is unloaded and in a safe condition before beginning installation.
- Gather necessary tools, if any, for the installation process.

### 2. Installation Steps:

- Align the slide cap with the designated area on the slide of the SIG SAUER P365.
- Gently press the slide cap into place until it fits securely.
- Ensure that the cap is seated properly and does not move or shift.

### 3. PostInstallation Check:

- After installation, check that the slide cap is securely attached.
- Perform a visual inspection to ensure there are no gaps or misalignments.

### 4. Usage:

- Use the firearm only in accordance with the manufacturer's guidelines and safety practices.
- Regularly inspect the slide cap during routine maintenance to ensure it remains in good condition.

## **Disposal Instructions**

- Dispose of the slide cap responsibly if it becomes damaged beyond repair or is no longer needed.
- Do not dispose of the slide cap in regular household waste. Instead, follow local regulations for the disposal of firearm accessories.

## **Contact Information for Further Support**

For safety inquiries or to report unsafe products, please refer to the EU Safety Gate platform for updates and further assistance.

By following these guidelines, you can help ensure your safety and the proper functioning of your SIG SAUER P365 NonTextured Slide Cap. Thank you for your attention to these important safety instructions.

# About Us

## **Brownells Česká republika**

**Brownells - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories**

[www.brownells.cz](http://www.brownells.cz)