

# CASE TRIMMER PILOT - FORSTER PRODUCTS, INC. 0.338" TRIMMER PILOT

[Reloading](#) > [Case Preparation](#) > [Case Trimming](#) > [Case Trimmer Pilots](#)

FORSTER Case Trimmer Pilot: .17 cal requires item 749-002-532 for use with Forster "Original" trimmers.



## Attributes

- Name: [FORSTER PRODUCTS, INC. 0.338" TRIMMER PILOT](#)
- Manufacturer: [FORSTER PRODUCTS, INC.](#)
- Product no.: 749000391
- Mfr. No.: CT103-
- Caliber: 338 Caliber (.338)
- Delivery weight: 0.032kg
- Shipping width: 57mm
- Shipping length: 89mm
- UPC: 757253003707

## Item details

Made in USA

# Table of Contents

- [Startpage](#)
- [CASE TRIMMER PILOT SAFETY INSTRUCTIONS](#)
- [About Us](#)

# CASE TRIMMER PILOT SAFETY INSTRUCTIONS

## Introduction

Thank you for choosing the Forster Case Trimmer Pilot. This guide provides essential safety instructions and information to ensure the safe and effective use of the product. Please read this manual carefully before using the Case Trimmer Pilot to familiarize yourself with its features and safety precautions.

## General Safety Guidelines

- Always use the Case Trimmer Pilot in accordance with the manufacturer's instructions to prevent accidents and injuries.
- Ensure that the workspace is clean, dry, and welllit to avoid any hazards during operation.
- Keep the product out of reach of children and vulnerable individuals to prevent misuse and accidents.
- Regularly inspect the Case Trimmer Pilot for any signs of damage or wear. Do not use if any parts are damaged.
- Follow all local regulations regarding the use and disposal of tools and equipment.

## Specific Safety Precautions for Use

- Always wear appropriate personal protective equipment (PPE), such as safety glasses and gloves, when operating the Case Trimmer Pilot.
- Do not operate the trimmer pilot near flammable materials or in explosive atmospheres.
- Ensure that the trimmer pilot is securely attached to the trimmer before use to prevent it from becoming loose during operation.
- Avoid placing hands or fingers near the cutting area while the trimmer pilot is in use.
- Do not attempt to modify or alter the Case Trimmer Pilot in any way, as this may compromise its safety and effectiveness.

## Instructions for Installation and Usage

### 1. Installation:

- Ensure the trimmer is unplugged or turned off before attaching the Case Trimmer Pilot.
- Align the trimmer pilot with the designated opening on the trimmer.
- Securely fasten the trimmer pilot in place according to the manufacturer's instructions.
- Doublecheck that the pilot is properly installed and does not wobble.

### 2. Usage:

- Turn on the trimmer and allow it to reach the necessary operating speed.
- Hold the case firmly in place against the trimmer pilot.
- Gently guide the case into the cutting area, ensuring that your hands remain clear of the cutting path.
- After trimming, turn off the trimmer and carefully remove the case from the pilot.
- Clean the trimmer pilot after each use to maintain its performance and safety.

## Disposal Instructions

- Dispose of the Case Trimmer Pilot in accordance with local regulations regarding electronic waste and tools.
- Do not dispose of the product in household waste. Instead, consider recycling options or returning it to a designated disposal facility.

## **Contact Information for Further Support**

For any inquiries regarding the safety and use of the Case Trimmer Pilot, please reach out to the manufacturer or your local distributor. Ensure you have the product details ready for a more efficient response.

By following these safety instructions, you ensure a safer and more effective experience with your Forster Case Trimmer Pilot. Thank you for prioritizing safety!

# About Us

## Brownells UK

### **Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories**

Unit 1, Laughing Dog Industrial Estate  
London Road  
Rugby  
Warwickshire  
CV23 9LP

[www.brownells.co.uk](http://www.brownells.co.uk)