

AUTO PRIME SHELLHOLDERS - LEE AUTO PRIME SHELLHOLDER #21

[Reloading](#) > [Shellholders & Shellplates](#)

Lee Universal Shell Holders function in the Lee handheld priming tools. Machined to close tolerances for maximum accuracy. Manufactured from hardened steel. View Lee Shellholder Chart



Attributes

- Name: [LEE AUTO PRIME SHELLHOLDER #21](#)
- Manufacturer: [LEE PRECISION](#)
- Product no.: 749000398
- Mfr. No.: 90031
- Cartridge: 6.8 mm Remington SPC, 224 Valkyrie, 30 Remington
- Style: Priming Tool
- Delivery weight: 0.032kg
- Shipping height: 5mm
- Shipping width: 53mm
- Shipping length: 58mm
- UPC: 734307900311

Item details

Made in USA

Table of Contents

- Startpage
- AUTO PRIME SHELLHOLDERS LEE AUTO PRIME SHELLHOLDER #21 Safety Instructions
- About Us

AUTO PRIME SHELLHOLDERS LEE AUTO PRIME SHELLHOLDER #21 Safety Instructions

Introduction

Thank you for choosing the AUTO PRIME SHELLHOLDERS LEE AUTO PRIME SHELLHOLDER #21. This product is designed for use with Lee handheld priming tools and is manufactured to ensure maximum accuracy and safety. Please read this safety instruction guide carefully to ensure safe and effective use of the product.

General Safety Guidelines

- Ensure that you are familiar with the operation of the Lee handheld priming tools before using the shellholder.
- Always handle the shellholder and priming tools with care to avoid injury.
- Store the shellholder in a safe place, away from children and vulnerable individuals.
- Regularly inspect the shellholder for any signs of wear or damage before use.
- Do not use the shellholder with any cartridges other than those specified in this guide.

Specific Safety Precautions for Use

- Only use the AUTO PRIME SHELLHOLDERS LEE AUTO PRIME SHELLHOLDER #21 with the following cartridges:
 - 6.8 mm Remington SPC
 - 30 Remington
 - 224 Valkyrie
- Ensure that the shellholder is securely attached to the priming tool before use.
- Do not exceed the recommended load limits for the cartridges.
- Always wear appropriate safety gear, including eye protection, when reloading ammunition.
- If you experience any difficulties during use, stop immediately and consult the user manual for your priming tool.

Instructions for Installation and Usage

1. Installation:

- Ensure the priming tool is turned off and not connected to any power source.
- Select the appropriate shellholder for your cartridge.
- Align the shellholder with the priming tool and securely attach it according to the tool's user manual.
- Doublecheck that the shellholder is firmly in place before proceeding.

2. Usage:

- Prepare your workspace by ensuring it is clean and welllit.
- Load the cartridge into the shellholder following the instructions in your priming tool's user manual.
- Follow the specific procedures for priming as outlined in the user manual for the priming tool.
- After use, remove the shellholder from the tool and clean it according to the manufacturer's recommendations.

Disposal Instructions

- Dispose of the shellholder in accordance with local regulations regarding metal waste.
- Do not dispose of the shellholder in regular household waste.

- If the shellholder is damaged or worn beyond safe use, consider recycling options available in your locality.

Contact Information for Further Support

For any inquiries or concerns regarding the AUTO PRIME SHELLHOLDERS LEE AUTO PRIME SHELLHOLDER #21, please consult the manufacturer's website or contact their customer service department for assistance.

Conclusion

By following these safety instructions, you can ensure a safe and effective experience with your AUTO PRIME SHELLHOLDERS LEE AUTO PRIME SHELLHOLDER #21. Always prioritize safety and refer to this guide whenever you have questions about the product's use.

About Us

Brownells Austria

Brownells - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

www.brownells.at