

AUTO PRIME SHELLHOLDERS - LEE PRECISION LEE AUTO PRIME SHELLHOLDER #5

[Reloading](#) > [Shellholders & Shellplates](#)

Lee Universal Shell Holders function in the Lee handheld priming tools. Machined to close tolerances for maximum accuracy. Manufactured from hardened steel. View Lee Shellholder Chart



Attributes

- Name: [LEE PRECISION LEE AUTO PRIME SHELLHOLDER #5](#)
- Manufacturer: [LEE PRECISION](#)
- Product no.: 749000422
- Mfr. No.: 90205
- Cartridge: Standard Belted Magnums
- Style: Priming Tool
- Delivery weight: 0.014kg
- Shipping height: 3mm
- Shipping width: 94mm
- Shipping length: 127mm
- UPC: 734307902056

Item details

Made in USA

Table of Contents

- Startpage
- AUTO PRIME SHELLHOLDERS LEE PRECISION Safety Instructions
- About Us

AUTO PRIME SHELLHOLDERS LEE PRECISION Safety Instructions

Introduction

Thank you for purchasing the AUTO PRIME SHELLHOLDERS LEE PRECISION LEE AUTO PRIME SHELLHOLDER #5. This guide provides essential safety instructions to ensure the safe and effective use of the product. Please read this document carefully before using the shellholder.

General Safety Guidelines

- Ensure that the product is used in accordance with the manufacturer's instructions to avoid any hazards.
- Keep the product out of reach of children and vulnerable individuals.
- Regularly inspect the shellholder for any signs of wear or damage. Do not use if damaged.
- Report any unsafe products or accidents to relevant authorities immediately.
- Stay informed about product recalls through the EU's Safety Gate platform.

Specific Safety Precautions for Use

- Always use the shellholder with compatible cartridges as specified by the manufacturer.
- Do not exceed the recommended limits for cartridge types and sizes.
- Use appropriate protective equipment, such as safety glasses, when handling ammunition and reloading tools.
- Ensure that your workspace is clean and organized to prevent accidents.
- Do not use the shellholder for purposes other than intended.

Instructions for Installation and Usage

1. Installation

- Ensure that the priming tool is clean and free of debris.
- Insert the AUTO PRIME SHELLHOLDER #5 into the priming tool securely.
- Verify that the shellholder is properly seated and locked in place.

2. Usage

- Select the appropriate cartridge for the shellholder.
- Follow the priming tool's instructions for loading and seating primers.
- Operate the priming tool smoothly and steadily to ensure proper primer seating.
- After use, remove the shellholder from the priming tool and clean it as necessary.

Disposal Instructions

- Dispose of the shellholder according to local regulations.
- Do not dispose of the shellholder in regular household waste if it is damaged or no longer usable.
- Consider recycling options if available in your area.

Contact Information for Further Support

For any safety inquiries or additional support, please refer to the manufacturer's contact information provided with the product packaging.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk