

AUTO PRIME SHELLHOLDERS - LEE AUTO PRIME SHELLHOLDER #12

[Reloading](#) > [Shellholders & Shellplates](#)

Lee Universal Shell Holders function in the Lee handheld priming tools. Machined to close tolerances for maximum accuracy. Manufactured from hardened steel. View Lee Shellholder Chart



Attributes

- Name: [LEE AUTO PRIME SHELLHOLDER #12](#)
- Manufacturer: [LEE PRECISION](#)
- Product no.: 749000425
- Mfr. No.: 90212
- Cartridge: 22 PPC, 6 PPC, 6.5 Grendel, 7.62 x 39 mm Russian
- Style: Priming Tool
- Delivery weight: 0.032kg
- Shipping height: 8mm
- Shipping width: 94mm
- Shipping length: 127mm
- UPC: 734307902124

Item details

Made in USA

Table of Contents

- Startpage
- AUTO PRIME SHELLHOLDERS LEE AUTO PRIME SHELLHOLDER #12 Safety Instruction Guide
- About Us

AUTO PRIME SHELLHOLDERS LEE AUTO PRIME SHELLHOLDER #12 Safety Instruction Guide

Introduction

Thank you for purchasing the Lee Auto Prime Shellholder #12. This product is designed to enhance your reloading experience by providing a reliable and accurate priming tool. Please read this safety instruction guide carefully to ensure safe and proper use of the product.

General Safety Guidelines

- Ensure that the product is used in a wellventilated area to avoid inhalation of any dust or debris.
- Always wear appropriate safety gear, including eye protection, while using this product.
- Keep the product out of reach of children and vulnerable individuals.
- Regularly inspect the shellholder for any signs of wear or damage before use.
- Do not use the shellholder for any purpose other than intended.
- Follow all local laws and regulations regarding ammunition reloading and safety.

Specific Safety Precautions for Use

- Use only with compatible cartridges: 6.5 Grendel, 7.62 x 39 mm Russian, 22 PPC, and 6 PPC.
- Ensure that the priming tool is securely attached to the shellholder before use.
- Do not exceed the manufacturer's recommended specifications for reloading.
- Avoid using excessive force when seating primers to prevent accidental ignition.
- Keep fingers and other body parts clear of the priming area during operation.
- If you encounter any malfunctions, stop using the product immediately and seek assistance.

Instructions for Installation and Usage

1. Installation:

- Ensure that your Lee handheld priming tool is clean and free of debris.
- Select the appropriate Lee Auto Prime Shellholder #12 for your cartridge.
- Align the shellholder with the priming tool and push it firmly into place until it clicks securely.

2. Usage:

- Prepare your cases by cleaning and inspecting them for defects.
- Insert the case into the shellholder, ensuring it is seated properly.
- Follow the instructions for your specific priming tool to seat the primer into the case.
- After use, remove the shellholder from the priming tool and clean it as needed.

Disposal Instructions

- Dispose of any damaged or worn shellholders in accordance with local regulations.
- Do not throw the product in regular household waste. Check for local recycling options or hazardous waste disposal facilities.

Contact Information for Further Support

For safety inquiries or further assistance, please contact your local retailer or the manufacturer directly. Ensure you have the product information ready for reference.

Thank you for following these safety instructions. Your adherence to these guidelines will help ensure a safe and enjoyable reloading experience with the Lee Auto Prime Shellholder #12.

About Us

Brownells Austria

Brownells - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

www.brownells.at