

AUTO PRIME SHELLHOLDERS - LEE AUTO PRIME SHELLHOLDER #2

[Reloading](#) > [Shellholders & Shellplates](#)

Lee Universal Shell Holders function in the Lee handheld priming tools. Machined to close tolerances for maximum accuracy. Manufactured from hardened steel. View Lee Shellholder Chart



Attributes

- Name: [LEE AUTO PRIME SHELLHOLDER #2](#)
- Manufacturer: [LEE PRECISION](#)
- Product no.: 749000444
- Mfr. No.: 90202
- Cartridge: 22-250 Remington, 243 Winchester, 45 Auto (ACP), 308 Marlin Express, 308 Winchester
- Style: Priming Tool
- Delivery weight: 0.032kg
- Shipping height: 1mm
- Shipping width: 97mm
- Shipping length: 127mm
- UPC: 734307902025

Item details

Made in USA

Table of Contents

- [Startpage](#)
- [AUTO PRIME SHELLHOLDERS LEE AUTO PRIME SHELLHOLDER #2 Safety Instruction Guide](#)
- [About Us](#)

AUTO PRIME SHELLHOLDERS LEE AUTO PRIME SHELLHOLDER #2 Safety Instruction Guide

Introduction

Thank you for choosing the Lee Auto Prime Shellholder #2. This product is designed to enhance your reloading experience by providing precise and reliable shellholding capabilities. To ensure your safety and the proper use of this product, please read and follow the guidelines outlined in this safety instruction guide.

General Safety Guidelines

- Always keep the product out of reach of children and vulnerable individuals.
- Ensure that the workspace is clean and free from distractions before using the product.
- Inspect the shellholder for any damage or wear before each use. Do not use if damaged.
- Use only compatible cartridges as specified in the product description.
- Always wear appropriate safety gear, including eye protection, when using reloading tools.
- Follow all local laws and regulations regarding the use and storage of ammunition and reloading components.

Specific Safety Precautions for Use

- Use the Lee Auto Prime Shellholder #2 only with the designated priming tools.
- Ensure that you are using the correct shellholder for the specific cartridge to prevent mishaps.
- Avoid overpriming. Follow the instructions provided with your priming tool for proper operation.
- Do not attempt to modify or alter the shellholder in any way.
- Store the shellholder in a safe, dry place when not in use to prevent corrosion or damage.

Instructions for Installation and Usage

1. Installation:

- Ensure that your priming tool is clean and free of debris.
- Select the correct Lee Auto Prime Shellholder #2 for your cartridge type.
- Insert the shellholder into the priming tool according to the manufacturer's instructions. Ensure it is securely in place.

2. Usage:

- Load the appropriate cartridge into the shellholder.
- Follow the priming tool's instructions to properly seat the primer.
- Maintain a stable and secure grip on the priming tool while operating it.
- After use, remove the shellholder from the priming tool and clean it if necessary.

Disposal Instructions

- Dispose of any damaged or worn shellholders in accordance with local waste management regulations.
- Do not throw the shellholder in regular household waste. Instead, check with local authorities for proper disposal methods for metal and reloading components.
- If you are discarding packaging materials, ensure they are disposed of in an environmentally responsible manner.

Contact Information for Further Support

For any questions or concerns regarding the Lee Auto Prime Shellholder #2, please consult the product's official website or contact a qualified retailer for assistance. Always ensure that you have the latest updates regarding product safety and recalls.

Thank you for your attention to these safety instructions. Your safety and satisfaction are our top priorities. Enjoy your reloading experience with the Lee Auto Prime Shellholder #2!

About Us

Brownells Austria

Brownells - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

www.brownells.at