

# UNIVERSAL DECAPPING DIE REPLACEMENT RODS - REDDING SMALL REPLACEMENT DECAPPING ROD

[Reloading](#) > [Reloading Dies](#) > [Replacement Parts & Upgrades](#)

One piece decapping rod and pin assembly for #749-002-640 Redding small decapping die. Decapping pin is .080 diameter.



## Attributes

- Name: [REDDING SMALL REPLACEMENT DECAPPING ROD](#)
- Manufacturer: [REDDING](#)
- Product no.: 749001068
- Mfr. No.: 69275
- Delivery weight: 0.005kg
- Shipping width: 102mm
- Shipping length: 152mm
- UPC: 611760692758

## Item details

Made in USA

# Table of Contents

- Startpage
- Safety Instruction Guide for UNIVERSAL DECAPPING DIE REPLACEMENT RODS REDDING SMALL REPLACEMENT DECAPPING ROD
- About Us

# **Safety Instruction Guide for UNIVERSAL DECAPPING DIE REPLACEMENT RODS REDDING SMALL REPLACEMENT DECAPPING ROD**

## **Introduction**

Thank you for choosing the Redding Small Replacement Decapping Rod. This guide provides important safety information and instructions to ensure the safe and effective use of this product. Please read this guide carefully before using the decapping rod.

## **General Safety Guidelines**

- Always use the decapping rod in accordance with the manufacturer's instructions.
- Keep the product out of reach of children and vulnerable individuals to prevent accidents.
- Inspect the decapping rod and pin assembly for any signs of damage or wear before each use.
- Do not modify the decapping rod or any of its components.
- Ensure that the work area is clean and free from obstructions to avoid accidents during use.
- Report any unsafe products or accidents to the relevant authorities.

## **Specific Safety Precautions for Use**

- Use personal protective equipment (PPE), such as safety glasses, to protect your eyes from debris.
- Do not apply excessive force when using the decapping rod, as this may lead to breakage or injury.
- Avoid using the decapping rod if you are tired or under the influence of substances that may impair your judgment.
- Follow all instructions for the proper assembly and disassembly of the decapping rod to prevent injury.
- Be cautious of sharp edges and points when handling the decapping rod and pin assembly.

## **Instructions for Installation and Usage**

### **1. Assembly of the Decapping Rod:**

- Ensure you have all components: the decapping rod and pin assembly.
- Insert the decapping pin into the designated slot in the decapping rod until it is securely in place.

### **2. Using the Decapping Rod:**

- Place the decapping rod into the appropriate die setup.
- Align the cartridge case properly with the decapping pin.
- Apply gentle, even pressure to decap the cartridge case. Avoid excessive force.
- After use, carefully remove the decapping rod from the die.

### **3. Maintenance:**

- Regularly clean the decapping rod and pin assembly to remove any debris.
- Check for wear and replace the decapping pin if it shows signs of damage.

## **Disposal Instructions**

- Dispose of the decapping rod and any damaged components in accordance with local regulations.
- Do not dispose of the decapping rod in general waste if it contains hazardous materials.

## **Contact Information for Further Support**

For any inquiries regarding the safety and usage of the Redding Small Replacement Decapping Rod, please refer to the manufacturer's contact information provided in the product packaging or visit their official website.

By following these guidelines, you can ensure the safe and effective use of the Redding Small Replacement Decapping Rod. Thank you for your attention to safety!

# About Us

## Brownells UK

### **Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories**

Unit 1, Laughing Dog Industrial Estate  
London Road  
Rugby  
Warwickshire  
CV23 9LP

[www.brownells.co.uk](http://www.brownells.co.uk)