

FLIP-OPEN OBJECTIVE LENS COVERS - BUTLER CREEK OBJECTIVE LENS COVER #48 2.500" (63.5MM)

[Optics & Mounting](#) > [Optic Accessories](#) > [Scope Lens Covers](#)

Keeps Harmful Debris From Scratching Or Abusing Lenses

Weatherproof, dust-proof, moisture-proof scope covers protect your scope's lenses from being damaged during tactical and hunting situations. Cover flips open easily with finger pressure to spring up, and out of the way. Eye and Objective covers sold separately. To determine the correct scope cover, measure the diameter of your scope eyepiece or objective and use the chart.



Attributes

- Name: [BUTLER CREEK OBJECTIVE LENS COVER #48 2.500" \(63.5MM\)](#)
- Manufacturer: [BUTLER CREEK](#)
- Product no.: 749001503
- Mfr. No.: 30480
- Colour: Black
- End Fit: Objective
- Model Number: 2.500" (63.5MM)
- Size: 2.500
- Delivery weight: 0.091kg
- Shipping height: 33mm
- Shipping width: 97mm
- Shipping length: 180mm
- UPC: 051525304807

Table of Contents

- Startpage
- Safety Instruction Guide for FLIOPEN OBJECTIVE LENS COVERS
- About Us

Safety Instruction Guide for FLIPOOPEN OBJECTIVE LENS COVERS

Introduction

Thank you for choosing the FLIPOOPEN OBJECTIVE LENS COVERS by Butler Creek. This product is designed to protect your scope's lenses from weather, dust, and moisture during tactical and hunting situations. Please read this safety instruction guide carefully to ensure safe and effective use of the product.

General Safety Guidelines

- Ensure safe use of the lens covers by following these guidelines:
 - Always check the product for damage before use.
 - Use the lens covers only for their intended purpose.
 - Keep the lens covers out of reach of children to prevent accidents.
 - Report any unsafe product conditions to the relevant authorities.
 - Stay informed about product recalls and safety updates via the EU Safety Gate platform.

Specific Safety Precautions for Use

- To ensure optimal safety while using the lens covers, observe the following precautions:
 - Do not force the cover open or closed; use gentle finger pressure.
 - Avoid using the lens covers in extreme weather conditions that exceed their specifications.
 - Do not expose the lens covers to sharp objects that may cause damage.
 - Regularly clean the lens covers to maintain visibility and performance.
 - Inspect the lens covers periodically for signs of wear or damage.

Instructions for Installation and Usage

- Follow these steps for proper installation and usage of the lens covers:
 1. **Measure Lens Diameter:** Determine the diameter of your scope's eyepiece or objective using a ruler or caliper.
 2. **Select the Correct Cover:** Refer to the product chart to ensure you have the correct size (2.500" or 63.5MM).
 3. **Installation:**
 - Align the cover with the lens.
 - Gently press the cover onto the lens until it fits securely.
 4. **Usage:**
 - To open the cover, apply light pressure with your finger to spring it up.
 - Ensure the cover is fully out of the way before using the scope.
 5. **Storage:** When not in use, store the lens covers in a dry and safe location.

Disposal Instructions

- Dispose of the lens covers responsibly:
 - Check local regulations for proper disposal methods.
 - If the lens covers are damaged beyond use, consider recycling if possible.
 - Do not dispose of lens covers in regular household waste if they contain hazardous materials.

Contact Information for Further Support

- For any inquiries regarding product safety or usage, please refer to the contact information provided in the product packaging or visit the manufacturer's website.

Thank you for adhering to these safety instructions. Proper use and care will enhance your experience with the FLIOPEN OBJECTIVE LENS COVERS.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk