

MULTI-FLEX FLIP-OPEN OBJECTIVE LENS COVERS - BUTLER CREEK OBJECTIVE LENS COVER #13,15 1.53-1.558" (38.9-39.6)

[Optics & Mounting](#) > [Optic Accessories](#) > [Scope Lens Covers](#)

These flip-open scope lens covers from Butler Creek will give you the same great lens protection as the standard covers we have carried for years. The Multi-Flex covers have additional flex in the collar so a wider range of scopes can be covered with each size. The tight, flexible skirt provides a custom fit for multiple scopes with the same features as the standard flip-open covers. Use Butler Creek Multi-Flex Sizing chart for cross reference to proper size.

Objective Lens Cover #13,15 1.53-1.558" (38.9-39.6)



Attributes

- Name: [BUTLER CREEK OBJECTIVE LENS COVER #13,15 1.53-1.558" \(38.9-39.6\)](#)
- Manufacturer: [BUTLER CREEK](#)
- Product no.: 749001557
- Mfr. No.: 31315
- Colour: Black
- End Fit: Objective
- Model Number: 1.53-1.558" (38.9-39.6)
- Size: 13 to 15 Objective
- Delivery weight: 0.023kg
- Shipping height: 41mm
- Shipping width: 71mm
- Shipping length: 122mm
- UPC: 051525313151

Table of Contents

- Startpage
- Safety Instruction Guide for MULTIFLEX FLIOPEN OBJECTIVE LENS COVERS
- About Us

Safety Instruction Guide for MULTIFLEX FLIOPEN OBJECTIVE LENS COVERS

Introduction

Thank you for choosing the MULTIFLEX FLIOPEN OBJECTIVE LENS COVERS by Butler Creek. This product is designed to protect your objective lenses from dust, dirt, and moisture. To ensure safe and effective use, please read this safety instruction guide carefully.

General Safety Guidelines

- Always ensure that the lens covers are properly fitted to the objective lenses before use.
- Regularly inspect the lens covers for any signs of wear or damage.
- Keep the product out of reach of children to prevent accidental injury or misuse.
- Report any unsafe conditions or incidents to the appropriate authorities immediately.
- Stay informed about recall updates through the EU's Safety Gate platform.

Specific Safety Precautions for Use

- Ensure that the lens covers are compatible with your specific objective lens sizes (13 to 15).
- Do not use the lens covers if they show any signs of damage or malfunction.
- Avoid exposing the lens covers to extreme temperatures or harsh chemicals.
- Do not force the lens covers onto the objective lenses; they should fit snugly but not require excessive force.
- If the lens covers become loose during use, stop using them immediately and check for damage.

Instructions for Installation and Usage

1. Installation

- Identify the correct size of your objective lens (13 to 15).
- Align the lens cover with the objective lens.
- Gently press the lens cover onto the objective lens until it fits snugly.

2. Usage

- Once installed, ensure that the lens covers are securely attached before transporting your equipment.
- To remove the lens covers, gently pull them away from the objective lens without twisting or forcing them.
- Store the lens covers in a cool, dry place when not in use.

Disposal Instructions

- Dispose of any damaged or unusable lens covers in accordance with local regulations.
- Do not dispose of the lens covers in household waste if they contain hazardous materials.
- Check with your local waste management authority for appropriate disposal methods.

Contact Information for Further Support

For any inquiries or additional support regarding the MULTIFLEX FLIOPEN OBJECTIVE LENS COVERS, please consult the product packaging for contact information or visit the manufacturer's website.

Thank you for prioritizing safety while using your MULTIFLEX FLIOPEN OBJECTIVE LENS COVERS. Your attention to these guidelines helps ensure a safe and enjoyable experience.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk