

MULTI-FLEX FLIP-OPEN OBJECTIVE LENS COVERS - BUTLER CREEK OBJECTIVE LENS COVER #30,31 1.96-1.998" (49.8-50.7MM)

[Optics & Mounting](#) > [Optic Accessories](#) > [Scope Lens Covers](#)

These flip-open scope lens covers from Butler Creek will give you the same great lens protection as the standard covers we have carried for years. The Multi-Flex covers have additional flex in the collar so a wider range of scopes can be covered with each size. The tight, flexible skirt provides a custom fit for multiple scopes with the same features as the standard flip-open covers. Use Butler Creek Multi-Flex Sizing chart for cross reference to proper size.

Objective Lens Cover #30,31 1.96-1.998" (49.8-50.7mm)



Attributes

- Name: [BUTLER CREEK OBJECTIVE LENS COVER #30,31 1.96-1.998" \(49.8-50.7MM\)](#)
- Manufacturer: [BUTLER CREEK](#)
- Product no.: 749001577
- Mfr. No.: 33031
- Colour: Black
- End Fit: Objective
- Model Number: 1.96-1.998" (49.8-50.7MM)
- Size: 30 to 31 Objective
- Delivery weight: 0.023kg
- Shipping height: 38mm
- Shipping width: 69mm
- Shipping length: 122mm
- UPC: 051525330318

Table of Contents

- Startpage
- MULTIFLEX FLIOPEN OBJECTIVE LENS COVERS SAFETY INSTRUCTIONS
- About Us

MULTIFLEX FLIOPEN OBJECTIVE LENS COVERS SAFETY INSTRUCTIONS

Introduction

Thank you for choosing the MULTIFLEX FLIOPEN OBJECTIVE LENS COVERS by BUTLER CREEK. This product is designed to protect your objective lenses and enhance your viewing experience. To ensure your safety and the proper use of this product, please read and follow the safety instructions outlined in this guide.

General Safety Guidelines

- Ensure that the lens covers are compatible with your objective lens size (30 to 31 Objective).
- Regularly inspect the lens covers for any signs of wear or damage before use.
- Keep the lens covers away from children and vulnerable individuals to prevent accidental injury or misuse.
- Use the product only for its intended purpose as specified by the manufacturer.

Specific Safety Precautions for Use

- Do not force the lens covers onto the objective lens if they do not fit easily.
- Avoid exposing the lens covers to extreme temperatures or harsh environmental conditions.
- Handle the lens covers with care to prevent scratches or damage to the surface.
- If the lens covers become damaged or compromised, discontinue use immediately and replace them.

Instructions for Installation and Usage

1. Installation:

- Ensure that the objective lens is clean and free of dust or debris.
- Align the lens cover with the objective lens, ensuring that it fits snugly.
- Gently press the lens cover onto the objective lens until it is securely in place.

2. Usage:

- To open the lens cover, gently flip it open while ensuring that the cover does not obstruct your view.
- When not in use, close the lens cover to protect the objective lens from scratches and environmental damage.

3. Maintenance:

- Regularly clean the lens covers with a soft, dry cloth to maintain clarity and prevent buildup of dirt.
- Avoid using harsh chemicals or abrasive materials when cleaning.

Disposal Instructions

- Dispose of the lens covers in accordance with local waste disposal regulations.
- Do not dispose of the product in household waste. Instead, consider recycling options if available.

Contact Information for Further Support

For safety inquiries or additional support regarding the MULTIFLEX FLIOPEN OBJECTIVE LENS COVERS, please refer to the manufacturer's contact information provided with your product.

Thank you for your attention to these safety instructions. Your safety and satisfaction are our top priorities.
Enjoy using your lens covers responsibly!

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk