

COMPETITION STANDARD LENGTH VLD SEATER STEMS - REDDING 7MM STANDARD VLD COMPETITION SEATING STEM

[Reloading](#) > [Reloading Dies](#) > [Replacement Parts & Upgrades](#)

Redding Competition Standard Length VLD Seater Stems. Stems are 1" long.



Attributes

- Name: [REDDING 7MM STANDARD VLD COMPETITION SEATING STEM](#)
- Manufacturer: [REDDING](#)
- Product no.: 749002244
- Mfr. No.: 55728
- Caliber: 284/7 mm (.284)
- Cartridge: 284 Caliber, 7mm
- Delivery weight: 0.023kg
- Shipping height: 3mm
- Shipping width: 83mm
- Shipping length: 146mm
- UPC: 611760557286

Item details

Made in USA

Table of Contents

- Startpage
- Safety Instruction Guide for Redding Competition Standard Length VLD Seater Stems
- About Us

Safety Instruction Guide for Redding Competition Standard Length VLD Seater Stems

Introduction

Thank you for choosing the Redding Competition Standard Length VLD Seater Stems. These components are designed to enhance your reloading experience while ensuring safety during use. This guide provides essential safety instructions and precautions to help you use the product safely and effectively.

General Safety Guidelines

- Always read and understand the product manual before use.
- Ensure that all reloading equipment is in good working condition.
- Keep the product out of reach of children and vulnerable individuals.
- Regularly check for product recalls or safety alerts on the EU's Safety Gate platform.
- Report any unsafe product incidents to the relevant authorities.

Specific Safety Precautions for Use

- Use only with compatible calibers: 284/7 mm (.284).
- Ensure that the reloading press is securely mounted and stable before use.
- Wear appropriate safety gear, including eye protection, when operating reloading equipment.
- Do not exceed recommended load specifications for your ammunition.
- Inspect the stems for any signs of wear or damage before each use.
- Avoid using the product in damp or wet conditions to prevent corrosion.

Instructions for Installation and Usage

1. Installation:

- Ensure your reloading press is powered down and unplugged.
- Remove any existing seating stems from the press.
- Carefully insert the Redding Competition Standard Length VLD Seater Stem into the seating die.
- Secure the stem in place according to the manufacturer's instructions.
- Doublecheck that the stem is properly aligned and tightened.

2. Usage:

- Prepare your brass cases and bullets according to standard reloading practices.
- Set the seating die to the desired depth based on your reloading specifications.
- Insert a brass case into the reloading press.
- Place a bullet on top of the case and activate the press to seat the bullet.
- Inspect the seated bullet for proper depth and alignment.
- Repeat the process for each round, ensuring consistent results.

Disposal Instructions

- Dispose of any damaged or worn components in accordance with local regulations.
- Do not dispose of the product in regular household waste. Check for recycling options in your area.
- Ensure that all components are disposed of safely to prevent environmental harm.

Contact Information for Further Support

For any safety inquiries or additional support regarding the Redding Competition Standard Length VLD Seater Stems, please refer to the manufacturer's contact details provided on the product packaging or visit their official website.

Thank you for prioritizing safety and compliance while using this product. Enjoy your reloading experience!

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk