

DECAP ROD ASSEMBLIES - REDDING DECAP ROD ASSEMBLY

[Reloading](#) > [Reloading Dies](#) > [Replacement Parts & Upgrades](#)

Includes decapping pin and expander ball Replacement decap rod assembly for Redding sizing dies.



Attributes

- Name: [REDDING DECAP ROD ASSEMBLY](#)
- Manufacturer: [REDDING](#)
- Product no.: 749002284
- Mfr. No.: 32956
- Cartridge: 25-20 Winchester, 256 Winchester Mag
- Diameter (in): -
- Delivery weight: 0.045kg
- Shipping width: 83mm
- Shipping length: 152mm
- UPC: 611760329562

Item details

Made in USA

Table of Contents

- Startpage
- DECAP ROD ASSEMBLIES REDDING DECAP ROD ASSEMBLY Safety Instructions
- About Us

DECAP ROD ASSEMBLIES REDDING DECAP ROD ASSEMBLY Safety Instructions

Introduction

Thank you for choosing the DECAP ROD ASSEMBLIES REDDING DECAP ROD ASSEMBLY. This product is designed to enhance your reloading experience by providing a reliable replacement decap rod assembly for Redding sizing dies. To ensure safe and effective use, please read and follow these safety instructions carefully.

General Safety Guidelines

- Always use the product in accordance with the manufacturer's instructions.
- Keep the product out of reach of children and vulnerable individuals.
- Inspect the product before each use for any signs of damage or wear.
- Report any unsafe products or accidents to the relevant authorities.
- Stay informed about product recalls by checking the EU's Safety Gate platform.

Specific Safety Precautions for Use

• Potential Hazards:

- Risk of injury from sharp edges or points, particularly from the decapping pin.
- Risk of damage to the reloading equipment if the decap rod assembly is not properly installed.

• Instructions for Avoiding Hazards:

- Always handle the decap rod assembly with care to avoid injury.
- Ensure that the decapping pin is securely attached before use.
- Do not attempt to modify the decap rod assembly in any way.
- Wear appropriate safety gear, such as safety glasses, while using the product.

Instructions for Installation and Usage

1. Installation:

- Ensure that your reloading die is clean and free of debris.
- Remove the old decap rod assembly from the sizing die.
- Insert the new DECAP ROD ASSEMBLY into the die, ensuring it is properly seated.
- Tighten any screws or fasteners according to the manufacturer's specifications.

2. Usage:

- Follow the reloading die's instructions for setting up your reloading press.
- Use the decap rod assembly as intended, ensuring that it is aligned correctly with the cartridge.
- Always check that the decapping pin is functioning properly before starting the reloading process.

Disposal Instructions

- Dispose of the product in accordance with local regulations.
- Do not dispose of the product in household waste.
- If the product is damaged or no longer usable, consider recycling materials where possible.

Contact Information for Further Support

For any inquiries regarding safety, usage, or product support, please refer to the manufacturer's contact details provided with the product packaging.

By following these guidelines, you can ensure a safe and effective reloading experience with the DECAP ROD ASSEMBLIES REDDING DECAP ROD ASSEMBLY. Thank you for prioritizing safety in your reloading activities.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk