

DECAP ROD ASSEMBLIES - REDDING DECAP ROD ASSEMBLY

[Reloading](#) > [Reloading Dies](#) > [Replacement Parts & Upgrades](#)

Includes decapping pin and expander ball Replacement decap rod assembly for Redding sizing dies.



Attributes

- Name: [REDDING DECAP ROD ASSEMBLY](#)
- Manufacturer: [REDDING](#)
- Product no.: 749002287
- Mfr. No.: 33263
- Cartridge: 260 Remington,6.5 Creedmoor,260 Remington Imp,6.5 x 54 mm Mannlicher
- Diameter (in): -
- Delivery weight: 0.045kg
- Shipping height: 1mm
- Shipping width: 102mm
- Shipping length: 152mm
- UPC: 611760332630

Item details

Made in USA

Table of Contents

- Startpage
- Safety Instruction Guide for DECAP ROD ASSEMBLIES REDDING DECAP ROD ASSEMBLY
- About Us

Safety Instruction Guide for DECAP ROD ASSEMBLIES REDDING DECAP ROD ASSEMBLY

Introduction

Thank you for choosing the DECAP ROD ASSEMBLIES REDDING DECAP ROD ASSEMBLY. This product is designed to provide reliable performance in decapping cases for various cartridges. Please read this safety instruction guide carefully to ensure safe and effective use of the product.

General Safety Guidelines

To ensure your safety and the safety of others, please adhere to the following guidelines:

- Always follow the manufacturer's instructions when using the product.
- Ensure that the product is used in a wellventilated area to avoid inhalation of any dust or particles.
- Keep the product out of reach of children and vulnerable individuals.
- Regularly inspect the decap rod assembly for signs of wear or damage before each use.
- Report any unsafe product conditions to the appropriate authorities.

Specific Safety Precautions for Use

When using the DECAP ROD ASSEMBLIES, please observe the following precautions:

- Use the product only for its intended purpose of decapping cases in Redding sizing dies.
- Wear appropriate personal protective equipment (PPE) such as safety glasses and gloves during use.
- Avoid using excessive force when inserting or removing the decap rod assembly to prevent injury or damage.
- Do not modify the product in any way, as this may compromise its safety and functionality.
- Ensure that the work area is free from clutter and distractions to maintain focus while using the product.

Instructions for Installation and Usage

To install and use the DECAP ROD ASSEMBLIES REDDING DECAP ROD ASSEMBLY, follow these steps:

1. Installation:

- Remove the existing decap rod assembly from your Redding sizing die by unscrewing it in a counterclockwise direction.
- Take the new DECAP ROD ASSEMBLY and align it with the die opening.
- Screw the decap rod assembly into the die by turning it clockwise until it is securely fastened.
- Ensure that the decapping pin and expander ball are properly positioned.

2. Usage:

- Place the cartridge case into the sizing die as per the manufacturer's instructions.
- Pull the handle of the reloading press to operate the sizing die, allowing the decap rod assembly to decap the case.
- After decapping, remove the cartridge case from the die and inspect it for any defects.
- Store the decap rod assembly in a safe place when not in use.

Disposal Instructions

When disposing of the DECAP ROD ASSEMBLIES, please follow these guidelines:

- Do not dispose of the product in regular household waste.
- Check local regulations for proper disposal methods for tools and equipment.
- If the product is damaged beyond repair, consider recycling any metal components where applicable.

Contact Information for Further Support

For any questions or concerns regarding the DECAP ROD ASSEMBLIES REDDING DECAP ROD ASSEMBLY, please refer to the manufacturer's contact information provided with the product packaging.

Thank you for your attention to these safety guidelines. Your safety is our priority, and we hope you enjoy using your new product.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk