

# DECAP ROD ASSEMBLIES - REDDING DECAP ROD ASSEMBLY

[Reloading](#) > [Reloading Dies](#) > [Replacement Parts & Upgrades](#)

Includes decapping pin and expander ball Replacement decap rod assembly for Redding sizing dies.



## Attributes

- Name: [REDDING DECAP ROD ASSEMBLY](#)
- Manufacturer: [REDDING](#)
- Product no.: 749002292
- Mfr. No.: 34263
- Cartridge: 264 Winchester, 6.5 x 55 mm Swedish Mauser, 6.5 x 57 mm Mauser, 6.5 mm - 06 (A-Square)
- Diameter (in): -
- Delivery weight: 0.045kg
- Shipping width: 102mm
- Shipping length: 152mm
- UPC: 611760342639

## Item details

Made in USA

# Table of Contents

- Startpage
- DECAP ROD ASSEMBLIES REDDING DECAP ROD ASSEMBLY Safety Instruction Guide
- About Us

# DECAP ROD ASSEMBLIES REDDING DECAP ROD ASSEMBLY Safety Instruction Guide

## Introduction

Thank you for choosing the DECAP ROD ASSEMBLIES REDDING DECAP ROD ASSEMBLY. This product is designed for use with Redding sizing dies and includes a decapping pin and expander ball. To ensure safe and effective use, please read and follow these safety instructions carefully.

## General Safety Guidelines

- Ensure that the product is used only for its intended purpose.
- Keep the product out of reach of children and vulnerable individuals.
- Regularly inspect the product for any signs of wear or damage before use.
- Follow all local laws and regulations regarding the use of reloading equipment.
- Report any unsafe products or accidents to the relevant authorities.
- Stay informed about product recalls through the EU Safety Gate platform.

## Specific Safety Precautions for Use

- Always wear appropriate safety gear, including safety glasses, when using reloading equipment.
- Handle all components with care to prevent injury.
- Avoid working in a cluttered or poorly lit environment.
- Do not use the decap rod assembly if it shows any signs of damage or if the decapping pin is bent or broken.
- Ensure that the decap rod assembly is securely attached before use to prevent accidents.

## Instructions for Installation and Usage

### 1. Installation:

- Carefully remove the decap rod assembly from its packaging.
- Inspect the assembly for any visible damage.
- Follow the manufacturer's instructions to install the decap rod assembly into the Redding sizing die.
- Ensure that the decapping pin is properly aligned and secured.

### 2. Usage:

- Set up your reloading station in a wellventilated area.
- Prepare your cartridge cases according to the reloading guidelines.
- Use the decap rod assembly to decap the cartridge cases as per the manufacturer's recommendations.
- Always check that the assembly is functioning correctly after each use.

## Disposal Instructions

- Dispose of any damaged or worn components in accordance with local regulations.
- Recycle packaging materials where possible.
- Do not dispose of the product in household waste if it contains hazardous materials.

## **Contact Information for Further Support**

For any inquiries or support regarding the DECAP ROD ASSEMBLIES REDDING DECAP ROD ASSEMBLY, please refer to the manufacturer's customer service or official website for assistance.

Thank you for your attention to these safety guidelines. Your safety is our priority.

# About Us

## Brownells UK

### **Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories**

Unit 1, Laughing Dog Industrial Estate  
London Road  
Rugby  
Warwickshire  
CV23 9LP

[www.brownells.co.uk](http://www.brownells.co.uk)