

DECAP ROD ASSEMBLIES - REDDING DECAP ROD ASSEMBLY

[Reloading](#) > [Reloading Dies](#) > [Replacement Parts & Upgrades](#)

Includes decapping pin and expander ball Replacement decap rod assembly for Redding sizing dies.



Attributes

- Name: [REDDING DECAP ROD ASSEMBLY](#)
- Manufacturer: [REDDING](#)
- Product no.: 749002324
- Mfr. No.: 24307
- Cartridge: 7.5 mm Schmidt Rubin,30-06 Improved 40,30-338 Winchester Mag,30-40 Krag,30-06 Springfield
- Diameter (in): -
- Delivery weight: 0.059kg
- Shipping height: 1mm
- Shipping width: 102mm
- Shipping length: 152mm
- UPC: 611760243073

Item details

Made in USA

Table of Contents

- Startpage
- DECAP ROD ASSEMBLIES REDDING DECAP ROD ASSEMBLY Safety Instructions Guide
- About Us

DECAP ROD ASSEMBLIES REDDING DECAP ROD ASSEMBLY Safety Instructions Guide

Introduction

Thank you for choosing the DECAP ROD ASSEMBLIES REDDING DECAP ROD ASSEMBLY. This product is designed to provide reliable performance when replacing the decapping rod assembly in Redding sizing dies. Please read this safety instruction guide carefully to ensure safe and effective use of the product.

General Safety Guidelines

- Ensure that the product is used only for its intended purpose.
- Always follow the manufacturer's instructions for installation and usage.
- Keep this product out of reach of children and vulnerable individuals.
- Regularly inspect the product for signs of wear or damage before use.
- Report any unsafe conditions or incidents to the appropriate authorities.

Specific Safety Precautions for Use

- Use only with compatible cartridges: 3006 Springfield, 3040 Krag, 7.5 mm Schmidt Rubin, 3006 Improved 40, 30338 Winchester Mag.
- Always wear appropriate safety gear, such as safety glasses, when handling reloading equipment.
- Ensure that the workspace is clean and free from distractions.
- Do not use excessive force when installing or removing the decap rod assembly.
- Avoid direct contact with the decapping pin and expander ball during operation.
- In case of any malfunction or unusual behavior, cease use immediately and consult a qualified technician.

Instructions for Installation and Usage

1. Preparation

- Gather all necessary tools and materials before starting the installation.
- Ensure that the Redding sizing die is clean and free from debris.

2. Installation of the Decap Rod Assembly

- Remove the existing decap rod assembly from the sizing die.
- Insert the new DECAP ROD ASSEMBLY into the sizing die, ensuring it is aligned properly.
- Secure the assembly in place according to the manufacturer's instructions.

3. Usage

- Follow the standard operating procedures for your reloading process.
- Monitor the performance of the decap rod assembly during use.
- If any issues arise, stop using the equipment and investigate the cause.

4. PostUse Care

- Clean the decap rod assembly and surrounding area after use.
- Store the product in a safe, dry place away from children and pets.

Disposal Instructions

- Dispose of the product in accordance with local regulations.
- Do not dispose of the product in regular household waste.
- Consider recycling options where available.

Contact Information for Further Support

For any safety inquiries or additional support, please refer to the manufacturer's contact information provided with the product packaging.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk